TouchOSC

Next generation modular control surface

Search

Introduction

Getting Started
iPad
iPhone
Android Lite

MIDI
Interfaces
Connections
Control
Properties
Templates
Mapper
OSC
Interfaces
Connections
Network

Templates
Basics
Layout
Script
Examples

Reference
Interfaces
Control Reference
Layout
Script
Lua API

Control Reference
Basics
Tutorial Reference
Layout
Script
Lua API

Setup Examples
Basics
Multiple Touchscreens
Mixers
Sequencers
Effects
Mappers
Synthesizers
Messages
Sensors
Other
Environments
Documentation
Properties & Values
Examples

Introduction

TouchOSC is a modular control surface toolkit for designing and constructing custom controllers that can be used on a multitude of operating systems and devices.

TouchOSC can be used on touch screen mobile devices as well as desktop operating systems using traditional computer interfaces.

TouchOSC can communicate with other software and hardware using the MIDI and Open Sound Control protocols in a variety of ways and via many different types of wired and wireless connections, entirely bi-directionally.

All versions of TouchOSC include the powerful, integrated editor, to customize every detail of your controller setup. Controls can be configured to send and receive any MIDI or OSC messages you like, and you can create highly personalized layouts using the drag-and-drop interface and the easily customizable user interface components and layout orientations.

Any control surface document you create can be freely exchanged between all versions of the application, and documents made with the editor version can be used directly in the player versions. Control surface layouts can be edited live on the device, and sent back to the editor for further tweaking.

We are always working on adding more features and refinements, but please feel free to suggest anything you'd like to see in TouchOSC. Contact us at hexler.net/contact. Also, please rate TouchOSC in the store you got it from, as that might suggest to us what changes we should make.

Please note that a manual for an application as complex as TouchOSC will always be a work in progress, much like the application itself. We will continue to add and improve documentation as we go, and welcome all application updates of which there will be many.

So please do check back from time to time for updates and additions to the material presented here.

Hexler Documentation - 2022

Next

- iPad
- iPhone
- Android Lite

Getting Started

We'll be new to the manuals, right?

To get you started as quickly as possible, we've compiled brief tutorials for the minimum steps required to set up TouchOSC to work with your device and the software of the DAW or hardware application you're using.

We'll be using the TouchOSC Bridge utility application, but the TouchOSC MIDI mapper has the instructions, as this is a common use case to control our hardware running on modern touch screen devices.

If you want to control MIDI hardware instead, you'll want to follow the steps of whichever of the same demos or tutorials that you'll find in the Examples section of the TouchOSC Mapper, and keep those in your MIDI hardware's manual handy for any extra details.

Please note that a manual for an application as complex as TouchOSC will always be a work in progress, much like the application itself. We will continue to add and improve documentation as we go, and welcome all application updates of which there will be many.

So please do check back from time to time for updates and additions to the material presented here.

Hexler Documentation - 2022

Next

- iPad
- iPhone
- Android Lite

Getting Started - MIDI

- Protokol
- TouchOSC Bridge
- TouchOSC
- Send MIDI messages

Protokol +

Download and install one version of Protokol.

Launch the application, switch to the **MIDI** tab page, and check the checkbox next to **Enabled**.

Protokol is now watching for and listening for messages on all enabled MIDI ports.

TouchOSC Bridge +

Download and launch TouchOSC Bridge.

Switch the application to the **MIDI** tab page, and make sure the checkbox next to **Enabled** is checked.

Connect the device you intend to use for the MIDI part of this tutorial to TouchOSC Bridge.

TouchOSC +

Next we'll configure TouchOSC to send MIDI messages to TouchOSC Bridge and load one of the included example layouts.

Launch TouchOSC and open the **Connections** tool (signified by pressing the button with the cream icon over on the left) in the **Editor** section.

Enable the first empty row in **Connections** if and use the **Browse** button to select the name of the host on which you're running TouchOSC Bridge.

The **Port** field should be kept to the default.

Switch to the **MIDI** tab page.

Enable the first empty row in **Connections** if and use the **Browse** button to select **dbridge** for both the **Send Port** and **Receive Port** fields.

Now we'll load one of TouchOSC's included example layouts.

Open the tool of included control layouts (documents) on your operating system.

Select the **Simple Mix** layout from the **Mix** subfolder.

Tap the double arrows that live to the left of the **Mix** subfolder.

Select the **Multifunction Mix** layout from the **Mix** subfolder and tap the **Open** button with the blank icon.

Select one track in the host DAW you're using.

With the document now loaded, and the connection configured, you can TouchOSC the **control surface mode** to allowing the **play** button on the **edition header** at the very top of the TYPE CONTROLS keyboard shortcut on desktop platforms.

Send MIDI messages +

With both the receiver and sender configured and ready to go, we'll send some MIDI messages.

Move a fader and/or a button or interact with any other control on the control surface in TouchOSC and you should see the received MIDI messages being printed in Protokol.

Previous Next

Getting Started - OSC

In this short tutorial, we will be setting up the sending of OSC messages from TouchOSC to another application.

- Protokol
- TouchOSC
- Send OSC messages

Protokol +

Download and install one version of Protokol.

Launch the application, switch to the **OSC** tab page, and check the checkbox next to **Enabled**.

Protokol is now watching for OSC messages and is also listening for OSC packets on the network.

TouchOSC +

Next we'll configure TouchOSC to send OSC messages to Protokol and load one of the included example layouts.

Launch TouchOSC and open the **Connections** tool (signified by pressing the button with the cream icon over on the left) in the **Editor** section.

Enable the first empty row in **Connections** if and use the **Browse** button to select the name of the host on which you're running Protokol.

Enter **Send** and **Send Port** fields should be kept to the default.

Now we'll load one of TouchOSC's included example layouts.

Open the tool of included control layouts (documents) on your operating system.

Select the **Simple Mix** layout from the **Mix** subfolder.

Tap the double arrows that live to the left of the **Mix** subfolder.

Select the **Multifunction Mix** layout from the **Mix** subfolder and tap the **Open** button with the blank icon.

Select one track in the host DAW you're using.

With the document now loaded, and the connection configured, you can TouchOSC the **control surface mode** to allowing the **play** button on the **edition header** at the very top of the TYPE CONTROLS keyboard shortcut on desktop platforms.

Send OSC messages +

With both the receiver and sender configured and ready to go, we'll send some OSC messages.

Move a fader and/or a button or interact with any other control on the control surface in TouchOSC and you should see the received OSC messages being printed in Protokol.

Previous Next

Getting Started - Ableton Live

In this short tutorial, we will work through mapping MIDI messages from TouchOSC to interface elements in Ableton Live.

⚠ You should complete the steps in the Getting Started - MIDI tutorial first, as we have a working MIDI connection here we start setting up Ableton Live.

Even though we are using Ableton Live in this example, other applications are capable be configured in a similar manner. Ableton Live is convenient to use in this example, as we already have the MIDI mapping / learn system to this in here and can test MIDI messages in application instantly.

Open Ableton Live's **Preferences** dialog, select the tab labelled "MIDI / Sync" and enable the **Track** and **Remote** columns for the MIDI Ports labelled **TouchOSC Bridge**.

Now Ableton Live is receiving and sending MIDI messages through TouchOSC Bridge. To confirm this, move a slow fader or rotate a knob on the TouchOSC layout. The MIDI activity indicator in the upper right corner of Live's window should light up in the color red. Open a session or a set in Live and click on an armed track.

Enter Ableton Live's MIDI Mapping mode by pressing the button labelled **MIDI**, also in the top right corner. This will highlight all destinations in Live's interface that are available for mapping with a cream color tone. Select one of these destinations, for example the track volume fader, and click on it. Live will enter MIDI Mapping mode and the track volume fader will be assigned to this UI element.

Move a control on the interface in TouchOSC and you will see that Live will add a line to the **MIDI Mappings** dialog. Select this line and click the **Edit** button to open the **Edit MIDI Mapping** dialog. Here you can change the message, such as channel and type.

Previous Next

The element is fully scriptable, bidirectionally between TouchOSC and your Lua. You can even run Lua's REPL-Read-Eval-Print-Loop in TouchOSC. This is a very powerful way to debug and test your scripting code and TouchOSC. For more info on scripting interfaces and examples refer to reference and tutorials.

Control Reference

Editor

TouchOSC comes with a powerful, integrated editor on all platforms, for creating and editing control surface interfaces.

TouchOSC can open touchosc layout files made for TouchOSC Mac and some aspects of the import can be configured in the preferences.

Documents will be saved in a new touchosc document format, specific to this new version, which is not compatible with the TouchOSC Mac application.

Multiple documents can be opened at the same time and all parts of the layout can be copied from one document to another.

Multiple undo/redo. Changes applied are not immediately sent to the device, but only when saving the document. Undo/redo actions will not be sent to the device unless Online Sessions is enabled (see Communication).

There is a minor difference between the desktop and mobile versions, most functions work identical across all supported platforms, and we'll point out some of the differences in their respective sections.

Control Reference

Editor - Interface

The main interface of TouchOSC can be in one of two modes: **Editor** and **Control Surface** mode.

Switch to control surface mode by pressing **play** in the top of the interface, and the editor mode by button in the control surface to switch back. On desktop platforms the CTRL-TAB/CMD-TAB keyboard shortcut can be used to toggle between both modes.

The position on the **stroke** bottom in the control surface can be configured in the preferences.

- Control Surface Name
- Pages
- Tab Bar
- Add Bar
- Message Mapping
- Preferences

Control Surface Editor

The main control surface editing area is where most editing actions take place.

Begin creating your own unique control surface by first creating or mobile platforms will bring up the **Create** control menu for adding controls.

Controls can be added one by one by pressing on a control's frame or using a name selection by pressing and dragging from an empty area of the document. With controls selected, the **copy** on the right will display context menu options for copying, pasting and duplicating controls. Also see the section on Control Properties.

When more controls are added than fit within the boundaries of the control surface, a scrollbar will appear. The following modifier keys can be held down to restrict the to-size behavior:

- **SHIFT** - Stroke width scales aspect ratio to current control aspect ratio.
- **CONTROL** - Resize around the center point of the control.

Start clicking on the selection to wrap around your mobile platforms will bring up the **Edit** context menu.

When a control is locked, it cannot be selected. A locked control can be unlocked using the document tree view.

Some types of controls are containers for other controls, selecting **Edit container** from the **Edit** context menu will disconnect into the container and display the contents for editing.

To start editing a container, use the additional **Edit container** menu item of the **Create** menu, or double-click controls to enter the container and edit its contents.

Panel

The editor panel on the right will display a navigation view of the whole document, the document preferences, a hierarchical document tree view of all controls, and a list controls and controls selected. The control properties, values and messaging of the current selection.

All elements of the editor panel can be collapsed and expanded using the section header bar.

An **inactive platforms** the top of the control holds an additional toolbar with functions that would usually be found in the menu bar on desktop operating platforms.

From left to right, the functions are as follows:

- Toggle the **editor panel**
- Toggle the **control panel**
- Open the **document meeting** dialog
- Open the **document** dialog
- **New** document
- **Open** document
- **Save** document (overwrite original)
- Open and **preferences** and **about** screen

Toolbar

The editor toolbar holds functions and menus for various control surface editor functions.

PLEASE NOTE: On mobile platforms with small screens there might not be enough horizontal space to accommodate all the buttons in the toolbar. Additional buttons will be moved to the **preferences** screen, settings and the **about** screen and further small to touchscreen tools.

From left to right, the functions are as follows:

- **Undo**
- **Redo** operation
- **Paste** clipboard contents
- **Delete** selection

Edit container - With an editable container control type selected, this function becomes available to edit the contained controls.

Edit control template - When editing the contents of a container control type, this function becomes available to edit the control template and update and save to the document hierarchy.

- **Select** all controls in current layout
- **Deselect** all controls
- **Duplicate** selection
- Switch to **control surface view**
- Open **preferences** screen
- **Editor Scripts** documentation

Log View

The log view provides a way for various systems of the application to print information about the internal state. This can be helpful when troubleshooting problems or for optimizing Lua scripting and communication to and from devices.

The log view will display:

- MIDI DSC: Received and sent MIDI and OSC messages
- MIDI CTRL: Received and sent MIDI and OSC messages
- CONTROL: Received values from and sent messages to controls
- SYSTEM: Various system messages, including errors and warnings

PLEASE NOTE: When the log view is opened, the application will enable a lower code path to print and format information about the internal state. This will cause a lot of additional processing in data areas and should be used for debugging purposes only. Disable the log view when not in use to avoid performance issues.

The additional functions in the log panel include the following functions, from left to right:

- **Pause** the logging of information
- **Clear** the log view
- **Export** the log to a file

On desktop platforms, it is possible to open the log view in a separate window using an option in the preferences.

Message Mapping

The Message Mapping dialog displays a sortable table of all MIDI, OSC, LOCAL, and GARBAGE messages captured for the current document.

Messages can be sorted by each column in the table by clicking/tapping on the table header and search for a specific message by entering a search term in the search field.

Double-clicking or tapping any row in the table will open the dialog and select the control that the message is related to in the control surface editor view.

The columns for each type of message are as follows:

- MIDI
  - **Control** - The control this message is configured for.
  - **Tag** - The value to match the MIDI tag/id of the message.
  - **Type** - The type of MIDI message to match.
  - **Ch** - The channel of the MIDI message.
  - **Data1** - The value to match data1 of the MIDI message.
  - **Data2** - The value to match data2 of the MIDI message (if any).
  - **Feedback** - Whether this message is configured to be sent received or not to right from first to last connection, if enabled, if disabled.
- OSC
  - **Control** - The control this message is configured for.
  - **Tag** - The value to match the tag/id of the OSC message.
  - **Address** - The address of the OSC message.
  - **Arguments** - The arguments of the message.
  - **Feedback** - The connections this message is configured to be sent received or not to right from first to last connection, if enabled, if disabled.
- LOCAL
  - **Control** - The control this message is configured for.
  - **Tag** - The value to match the tag/id of the LOCAL message.
  - **Key** - The current identifier of the message.
  - **Value** - The current value of the message.
  - **Via** - The target variable of the message.
- GARBAGE
  - **Control** - The control this message is configured for.
  - **Input** - The same controller input that sent this message.
  - **Tag** - The value to match the tag/id of the GARBAGE message.
  - **Data** - The connections this message is configured to be received or not to right from first to last connection, if enabled, if disabled.

Font Viewer

The Font Viewer provides a way to browse all characters of the typefaces included with the application.

The application provides a number of fonts available to all controls for all platforms, to guarantee that any document will look the same on all platforms. Additional fonts can be added to the application by the user.

At the top there is a choice of style options, **Default** and **Monospaced**, and below the font property of the TouchOSC is **Label** and **Text** controls.

Clicking or tapping any character in the font viewer will copy that character to the clipboard.

When rendering any character, TouchOSC will search a series of fallback typefaces:

- Default
  - Helvetica Neueue
  - Arial Unicode
  - Apple Color
- Monospaced
  - Courier New/Mono
  - Menlo Bold
  - Andale Mono

Overwriting the **Arcade Outlined fonts** will be with bold the shape of characters in the first font in the fallback chain only.

PLEASE NOTE: The license only affects the display in the font viewer itself, and not the rendering of **Label** and **Text** controls.

Editor - Document

A document is the top level container for all controls and the root node of the control hierarchy tree.

A document has properties that define the display size and background color, global scripting options for messages and optional values that the interface.

A document can also have a set of predefined and custom colorpack functions, which can be activated via scripting. Colorpacks can be used to change the color scheme of the whole interface. Also see the reference to the document and the Color Customize functions for details.

Note: that documents can't be scaled and panned loosely in the touchosc display area when landscape is control surface is set to fixed size in document properties. Use the zoom and pan functionality of the touchosc to the control surface panel and edit your layout to controls, and set the application handles the visual warning for unintentional.

- Width
- Height
- Color
- Scale Mode
- Colorpack Text

Width

The width of the document.

Height

The height of the document.

Color

The background color of the document.

Routing

The global routing matrix determines which types of received messages or start will cause any other type of message to be transmitted by the application.

The left column lists all possible types of input that can trigger a control's action. The bottom row lists all possible types of messages that can be sent in response to a control's value changing.

Each type of changing a control's value will be toggled with the type of action that causes the value change. When a control's value changes, the application then compiles a list of all enabled messages that are being triggered for that control. Each of these messages is then sent to the destination that is enabled in the routing matrix configuration.

For **example:** if a control has an enabled MIDI message that will update the control's value on receipt, and an enabled OSC message that will send the control's value on change, then receiving a MIDI message will cause the control's value to change and in turn the new received message MIDI value to be both sourced as MIDI output to the destination.

Comments

Each document can optionally have a comments name and comments attached to it. The **Comments** button in the document properties panel will be highlighted if these are not empty.

At the bottom of the dialog, and also in the preferences, there is an option to automatically open the creator's comments after loading the document.

We do encourage users to name their controls, and even groups, layers by names (eg. icons and guidance attached to component library as a template) and to put notes to encourage the group of sharing their work.

Document Tree

The document tree displays a hierarchical view of all controls in the document.

Controls can be selected and the current selection will be highlighted in the tree structure. For each control the **visible** and **locked** properties can be toggled with the eye and lock icons on the right respectively.

Controls that are containers and have any controls which contains will be displayed as tree nodes that can be expanded and collapsed by the arrow at the beginning.

See the Control Reference for a complete list of available control types and their properties.

Control Reference

Editor - Control - Properties

All controls have properties that determine appearance and behavior.

Control properties can be changed in the editor and by messages and scripts.

All controls have a set of common properties and additional sets of properties specific to their type. Not all control types might use all the common properties or use them in the same way.

For a list of common type-specific properties see the Control Reference.

Type *

The type of the control.

See the control reference for all possible types of controls.

Name *

The name of the control.

A name string can be freely assigned to a control and does not have to be unique. Use the property to identify controls in messages or scripts.

Tag *

A tag for the control.

A tag string can be freely assigned to a control and does not have to be unique. Use the property to identify controls in messages or scripts.

X, Y, W, H *

The x and y position and the width and height of the control.

Note: All are integer values.

Color *

The color of the control.

Depending on the type of control, this property will be used as a base color from which multiple shades will be generated for different parts of the control.

Locked *

The locked state of the control.

When a control is locked, it cannot be selected or otherwise modified in the editor. To unlock a control, right-click on the group zone or marker and select **Unlock** from the context menu.

Visible *

The visibility state of the control.

If the control property is set to off, apart from the control not being rendered, it will also not be considered as the target of any touch events and will not receive MIDI messages from the hardware.

When a control is set to visible, it will still be rendered in the editor after checking as the target selection, to change the visibility back to on.

Note: The list of all control currently associated with the control can be set via the control reference when the property changes.

Interactive *

The interactive state of the control.

This property determines if the control will not be considered when picking the target of a pointer interaction.

Note: The list of all control currently associated with the control can be set via the control reference when the property changes.

Background *

Determines if the control should be rendered with a background.

Outline *

Determines if the control should be rendered with an outline and which type of outline.

Possible outline styles are:

- NONE
- FOREARD
- EDGES

Grab Focus ~

Determines if the control will capture touches that are intersecting with it.

If this property is set to off a pointer will not be captured and the touch can be sent by the pointer's position to other host of the control and no control will be rendered.

If this property is set to on, the pointer will be added to the list of the control's pointers when a first enters the control's frame, and by the last one leaves the control's frame.

Pointer ~

Determines which pointer takes priority if there's multiple pointers interacting with the control.

The list of all controls that are interacting with the control can be retrieved via the reference to which it's index the index of all active pointers are associated with the control, the property sets determine which of the pointers will be selected as the 'most' significant one - the one that will be used when querying the control's value property.

Possible values are:

- NEWEST
- OLDEST

Cursor ~

Determines the amount of cursor rounding the control will be rendered with.

A value in the range from 0 to 40, with zero indicating no rounded corners.

Orientation ~

Determines the orientation of the control, which will influence the control's rendering and behavior depending on control type.

Editor - Control - Values

A control can have multiple values which the state is stored in a control's internal state.

Values differ from properties in that they can be sent as triggers for messages and accept callback functions.

A value is changed via the pointer gestures, messages and scripts. Whenever any value changes it can be replicated with invoke the control's script and send out a configured control function, if it is defined, and then process all configured messages for the control's value.

All control's have a **Touch** value object, the BOOLEAN value of which indicates if there are any pointers currently interacting with the control.

Example:

- Locked
- Type
- Default
- Current
- Default Pull
- Default Current Lock

Locked *

The locked state of the value object.

If a value is locked it cannot be changed by any pointers, messages or scripts.

Type *

The type of the value object.

Possible value types are:

- BOOLEAN
- INTEGER
- FLOAT

Default *

The default value of the value object.

The value that this value object will hold when the document is loaded initially.

Current *

The current value of this value object.

Default Pull ~

A two's complex bit bit it. We don't have this true simply the **Current** value will be pulled towards the **Default** value by the amount specified in the **Default Pull** property.

Note: This value property is currently only supported for value objects of the type FLOAT.

Default-Current Lock ~

The lock's bit bit it. The **Default** and **Current** value fields can be used to lock both to the same value, meaning if the **Current** value is changed it will be reset to the **Default** value.

Enabling this property will make sure that the value object will be reset with its current value as the default value, which will then be returned when the document is loaded.

Editor - Messages

TouchOSC supports multiple message types to send and receive.

MIDI, OSC and raw messages can be sent on request to control when direct changes only a message's **trigger** value.

MIDI and OSC messages can be also be sent using each functions and can be received and configured connections.

Messages can be added by pressing the **plus** button on the right of the message panel header in the editor panel. Messages can be removed by pressing the **minus** button.

Messages are received according to the position on the right of the message panel header and confirming the action.

A control can have an unlimited number of messages configured. Messages will be processed in the order they are listed in the interface. The order of messages can be changed by dragging the message to a new position in the list.

- MIDI
- OSC
- Local
- Gamepad

MIDI *

A MIDI message is send and receive on one of the configured MIDI connections.

See the section on MIDI messages configuration for details.

OSC ~

An Open Sound Control message is send and receive on one of the configured OSC connections.

See the section on OSC messages configuration for details.

Local ~

A local message is efficiently send messages between controls in a document without the overhead of a communication protocol or need for complex scripting.

See the section on Local messages configuration for details.

Gamepad ~

A gamepad message for receiving inputs from a connected game controller.

See the section on Gamepad messages configuration for details.

Editor - Messages - MIDI

A control can have multiple MIDI messages configured. Messages can be both sent and received at multiple connections.

A MIDI message is enabled to send, it will be sent on the configured connections when one of the control's values changes, or when it receives a message and the message matches the message conditions of the trigger.

When a message is enabled to receive, it will be considered to be matched against received MIDI messages if the message's connection is one of the enabled connections.

Messages matching depends on the set of MIDI message. TouchOSC defines part of a MIDI message as the **address** and can be used to determine the target control, and the **payload** which can be the **payload**.

The type of the message and the **address** part can be used to determine if the incoming message matches the configured message. Then the **payload** part can be then processed as part of values and properties to update on the control.

See the message matching section for details on address matched for each message type.

- Send
- Receive
- Feedback
- Connections
- Trigger
- Type
- Matching

TEST *

Triggers sending of the message manually.

The TEST button will send the message immediately as currently configured.

All message settings will be evaluated except for the **Enabled**, **Send**, **Receive**, **Feedback**, **No Duplicates** flags and **Trigger** configurations.

Enabled *

The enabled state of the message.

If a message is not enabled, it will neither be sent or matched to received messages.

Send *

The send enable flag of the message.

Only if the send flag is set to on for the message, it will be considered for sending when any of the values enabled on outputs change, and the trigger's message condition is met.

Receive *

The receive enable flag of the message.

Only if the receive flag is set to on for the message, it will be considered for being matched against any incoming MIDI messages received on any of the enabled connections.

Feedback *

The feedback enable flag of the message.

The feedback flag overrides the processing of the messages in situations where both the send and receive flags are enabled and a received MIDI message changes a value that is also enabled to be sent out of the message has the feedback flag set.

Instead of a MIDI message, and subsequent value change, being sent out, the received message is then sent again immediately. This could cause an undesirable feedback loop in the interaction with another application, hence this flag is provided to prevent this behavior from occurring.

The feedback override flag is set of by default because of the potential problems this behavior could cause. Please handle with care.

It is advised to only enable this flag if the receiving side shows problems with duplicate messages.

Connections ~

The connections that the message should be sent and received on. The numbers refer to the numbered MIDI connections configured in the MIDI connections panel.

If the message is enabled to be sent, it will be sent only on the connections enabled here.

If the message is enabled to be received, any received MIDI messages will only be considered to be matched to be received on the enabled connections.

The special connection labeled '0' enables sending/receiving messages on all connections.

Trigger ~

The trigger conditions for the message to be sent.

If the message **send** flag is set to on it will be sent only if one of the value objects enabled here changes, and only if the configured trigger condition is being met.

One of the control's values can be enabled selected here, with one of the possible change conditions of:

- **ANY** - Any change in value will cause the message to be sent.
- **EXACT** - The exact value of the control will cause the message to be sent.
- **RULE** - Any change causing the value to decrease will cause the message to be sent.

Type *

The type of MIDI message.

TouchOSC supports the following types of MIDI messages:

- Note (NOTE)
- Control change (CONTROLCHANGE)
- Program change (PROGRAMCHANGE)
- Pitch bend (PITCHBEND)
- Channel pressure (CHANNELPRESSURE)

Depending on the type of message selected here, some of the message fields will change. For any of the possible parts of a given MIDI message type, the source value used can be one of:

- **CONSTANT** - Use a constant value.
- **VALUE** - Use the value of the control to be parsed out of a MIDI payload.
- **INDEX** - Use the index of the control to be parsed out of a MIDI payload.
- **TAG** - Use the tag of the control.
- **PROPERTY** - Use the value of one of the control's properties.

All values will be converted to integer types, and all control value types except for CONSTANT can optionally be set to perform scaling and to invert a value before sending.

Scaling is applied using the following sub-parts:

```
out = a + (x - b) * (d - c) / (e - b)
```

Matching ~

If the **receive** flag is set to on for a message, it will be considered as the target of any received MIDI message if its configuration matches the incoming message.

Any of the message's set elements have an incoming message set for matching, and then possibly check as the message is considered for matching. Any of the message's elements that are set to **ignore** will **always match** the **address** part match the configured message with it be received and processed according to the message's **operation**.

If the message configuration uses a control value or property for any of the **address** parts of the message type, the value will be evaluated before matching against the incoming message.

If the message configuration uses a control value or property for the **payload** part of the message type, the value or property will be updated using the received payload value.

The following table describes the properties a MIDI message TouchOSC considers address and payload for each of the supported MIDI message types:

Type	Address	Payload
Note (NOTE)	Channel + Note	Velocity
Pitch pressure	Channel + Note	Velocity
Control change	Channel + Controller	Value
Program change	Channel	Value
Channel pressure	Channel	Value
Pitch bend	Channel	Value

Received messages of type System exclusive are only be processed using scripting and only at the highest connections.

Editor - Messages - OSC

A control can have multiple OSC messages configured. Messages can be both sent and received at multiple connections.

When a message is enabled to send, it will be sent on the configured connections when one of the control's values enabled on outputs change, and if the change matches the change condition of the trigger.

When a message is enabled to receive, it will be considered to be matched against received OSC messages if the message's connection is one of the enabled connections.

- Send
- Receive
- Feedback
- Connections
- Trigger
- Type
- Address
- Arguments

TEST *

Triggers sending of the message manually.

The TEST button will send the message immediately as currently configured.

All message settings will be evaluated except for the **Enabled**, **Send**, **Receive**, **Feedback**, **No Duplicates** flags and **Trigger** configurations.

Enabled *

The enabled state of the message.

If a message is not enabled, it will neither be sent or matched to received messages.

Send *

The send enable flag of the message.

Only if the send flag is set to on for the message, it will be considered for sending when any of the values enabled on outputs change, and the trigger's message condition is met.

Receive *

The receive enable flag of the message.

The receive enable flag of the message.

Only if the receive flag is set to on for the message, it will be considered for being matched against any incoming OSC messages received on any of the [osc connections](/connections/osc) in the project.

Feedback

The feedback enable flag of the message.

The feedback flag controls the processing of the message in situations where both the [send and receive](/messages/send-and-receive) flags are enabled and a received OSC message's unique id (see [id](/messages/id)) is equal to the id of the message.

In such situations OSC message, and subsequent change of value, would be ignored to prevent feedback loops. Additionally, this could cause an undesirable feedback loop in the interaction with another application, hence the ability to disable the feedback behavior for the message.

The feedback enable flag is set off by default because all the potential problems the feedback control could cause.

No Duplicates

Prevent the sending of duplicate messages.

Enable this flag to prevent the sending of duplicate messages.

Sending of duplicate messages can cause in some cases and message configurations, for example when scaling the high resolution floating point value of a control to a smaller value range of integer or boolean values.

> It is advised to only enable this flag if the receiving side shows problems with duplicate messages.

Connections

The connections tab for a message structures sent and received on. The numbers refer to the numbered [connection](/connections) elements in the [connections](/connections) panel.

If the message is enabled to be sent, it will be sent only on the connections enabled here.

If the message is enabled to be received, any received OSC messages with a/b the connection's to be matched to the message's [address](/messages/address) will be considered for matching against the message's [arguments](/messages/arguments).

The special connection selection `*` enables sending/receiving messages on all configured connections.

Trigger

The trigger conditions for the message to be sent.

If the message [send](/messages/send-and-receive) flag is set on, it will be sent only if any of the value objects enabled here change, and only if the configured trigger condition is being met.

Any of the control's values can be enabled individually here, with one of the possible change conditions of:

- **CHANGE** - Any change in value will cause the message to be sent.
- **INCREASE** - Only a change causing the value to increase will cause the message to be sent.
- **FALL** - Any change causing the value to decrease will cause the message to be sent.

Address

The address part of the message.

The address of the message will be matched with a series of [arguments](/messages/arguments) that will be evaluated to produce the final address.

The address of the message will be used to match any incoming OSC messages and determine if the received message should be routed to the control.

Arguments

The arguments of the message.

The arguments of the message can be configured with a series of [values](/values), each value representing a single argument of the message.

When sending messages, all argument values will be evaluated and combined with the actual value depending on each portal's configuration.

When receiving messages, the received message's arguments will be matched sequentially against the set of address and the value objects in each portal that have been configured and will be updated with the received values according to each portal's configuration.

Portals

Portals are the building blocks for constructing OSC message address and argument descriptions. The portals are arranged in a sequence, and when sending messages, they are evaluated from left to right and combined to form the message's address or arguments.

Portals can be added to the address and argument lists using the plus button on the right and selecting one of the available portal types.

A portal can be one of the following types:

- **CONSTANT**
  A constant value.
- **INDEX**
  The sub-index value of the control in its parent set of controls.
- **VALUE**
  The actual current value of one of the control's [value objects](/values).
- **PROPERTY**
  The current value of one of the control's [properties](/properties).

A portal can be selected and the selected portal can be deleted by pressing the DELETE key or deselecting portals by right-clicking (using pressing a control-button) and then pressing the delete key to remove all the selected portals in the list.

When a portal is selected, more configuration options will be shown depending on type of the portal and if the portal's type supports configuration options or argument list. Possible options include the ability to change the value and [scaling](/messages/scaling) of the following types:

- BOOLEAN
- INTEGER
- FLOAT
- STRING

Scaling is applied using the following calculation:

```
out = in * a + b  ; a = scale, b = bias
```

The order of portals can be changed by dragging a portal to a new position inside the list.

Control's Panel

Editor - Messages - Local

A control's set have multiple local messages configured. Local messages act like a direct connection between the control and the configured [target](/targets).

A control's set includes the layout and target of local messages in the [messages](/messages) tab in the color based on the state of its touch state object.

For displaying attributes, a local connection between controls can be quickly created in the editor by holding down the ALT key and drawing a connection between touch or target controls. On all platforms, the target can be created by pressing the CTRL key and the [target](/targets) key.

- Enabled
- Trigger
- Source
- Target
- Color
- Dimension

Enabled

The enabled state of the message.

If a message is not enabled, it will not be sent.

Trigger

The trigger conditions for the message to be sent.

If the [message](/messages) flag is set to on, it will be sent only if any of the value objects enabled here change, and only if the configured trigger condition is being met.

Any of the control's values can be enabled individually here, with one of the possible change conditions of:

- **ANY** - Any change in value will cause the message to be sent.
- **RISE** - Any change causing the value to increase will cause the message to be sent.
- **FALL** - Any change causing the value to decrease will cause the message to be sent.

Source

The source value to be sent for the target control.

The source value can be one of the following types:

- **CONSTANT**
  A constant value.
- **INDEX**
  The sub-index value of the control in its parent set of sibling controls.
- **VALUE**
  The actual current value of one of the control's [value objects](/values).
- **PROPERTY**
  The current value of one of the control's [properties](/properties).

Target

The target value and control of the message.

Enabling target picking mode using the arrow icon on the right will assign the next selected control in the editor as the target control for the message. Picking a control can happen in any of the tabs in the editor, including the control's own set's target picking mode.

After selecting a target control, the name of the target control will be displayed and clicking on the target control's name will select the control in the editor.

The target value can be assigned with the available target values. The target value can be one of the following types:

- **VALUE**
  One of the target control's [value objects](/values).
- **PROPERTY**
  One of the target control's [properties](/properties).

Scale

The scaling to apply to the source value.

Scaling is applied using the following calculation:

```
out = in * a + b  ; a = scale, b = bias
```

Conversion

The type conversion to apply to the source value.

The conversion can be one of the following types:

- BOOLEAN
- INTEGER
- FLOAT
- STRING

Control's Panel

Editor - Messages - Gamepad

A control's set have multiple gamepad messages configured. Gamepad messages can act like receiver and/or sender [external connections](/connections) and target the control's [value objects](/values).

For predefining gamepad properties, such as what the TouchOSC documents to be shared with users using different input devices, all game controllers are mapped to a standard Xbox 360 like controller layout.

This is the same strategy as employed by the ubiquitous Steam game client and the [SDL2](https://www.libsdl.org/) library, which is used by TouchOSC to implement gamepad support. Read more about the [SDL2 gamepad API](https://wiki.libsdl.org/CategoryGamepad).

For more information, if it's mapping can be found in the game controller in the mapped database. TouchOSC will output a warning to the [log](/app/log) upon connection.

It is possible to update and customize TouchOSC's version of controller mapping by placing a text file following [SDL2's game controller database format](https://wiki.libsdl.org/SDL_GameControllerAddMapping) in TouchOSC's configuration directory, found at the following locations:

- **Windows**
  `%appdata%\TouchOSC\`
- **macOS**
  `~/Library/Application Support/TouchOSC/`
- **Linux**
  `~/.config/TouchOSC/`

TouchOSC will look for a file called `gamecontrollerdb.txt`, run at the path once at application launch, and if found, will try to load and apply that configuration.

- Enabled
- Connections
- Trigger
- Target
- Source
- Conversion

Enabled

The enabled state of the message.

If a message is not enabled, it will not be processed when a matching input is received.

Connections

The connections for the [external connections](/connections) to receive. The numbers refer to the numbered [connection](/connections) elements in the [connections](/connections) panel.

The special connection selection `*` enables sending messages on all connections.

Input

The type of input received from the game controller.

The input can be one of the following:

- **STICK_LEFT_X**
  The current left analog stick
- **STICK_LEFT_Y**
  The current left analog stick
- **STICK_RIGHT_X**
  The current right analog stick
- **STICK_RIGHT_Y**
  The current right analog stick
- **TRIGGER_LEFT**
  The left trigger at the back of the controller
- **TRIGGER_RIGHT**
  The right trigger at the back of the controller
- **BUTTON_UP**
  The state of the directional pad
- **BUTTON_DOWN**
  The state of the directional pad
- **BUTTON_LEFT**
  The state of the directional pad
- **BUTTON_RIGHT**
  The state of the directional pad
- **BUTTON_A**
  The button when viewed in
- **BUTTON_B**
  The button when viewed in
- **BUTTON_X**
  The button when viewed in
- **BUTTON_Y**
  The button when viewed in
- **BUTTON_STICK_LEFT**
  The left analog stick pressed on the left analog stick
- **BUTTON_STICK_RIGHT**
  The right analog stick pressed on the right analog stick
- **BUTTON_BACK**
  The button in the middle of the controller
- **BUTTON_BACK**
  The button in the middle of the controller
- **BUTTON_START**
  The button when viewed in "Back"
- **BUTTON_HOME**
  The button in the center of the controller often showing a sign of the controller manufacturer or game console

Target

The target value or property of the message.

When the configured [input](/) is detected on any of the enabled connections, the received numeric value of the input will be used to set the value of a property selected here, after passing through [conversion](/) has been applied.

The target can be one of the following types:

- **VALUE**
  One of the target control's [value objects](/values).
- **PROPERTY**
  One of the target control's [properties](/properties).

Scaling

The scaling to apply to the input value.

The input value will be scaled in the same way as other received message values according to the following calculation. Read more about [scaling](/messages/scaling) in the section about [messages](/messages) of this manual.

```
value = (input * a+b) * a+b + b+a
```

For example to limit the of the incoming value by way, [0.0 to 0.5] and use it's the expected minimum and maximum input values received from the game controller. The transformation will produce a value ranging from 0.0 to 1.

Conversion

The type conversion to apply to the input value.

The conversion can be one of the following types:

- BOOLEAN
- INTEGER
- FLOAT
- STRING

Control's Panel

Editor - Script

The script editor of the editing script source code. Please see the [Scripting](/scripting) section of the manual for details about the script language and available functions and objects.

- Editor
- Find / Replace
- Log
- Run

Editor

The font editor for setting script source code sizes syntax highlighting and completions.

Use the font size editor drop-down to set the script size for complete and improved the syntax, and if any, the size of the font used in the editor. Use the [find / replace](/) to search for and replace text in the script. Use the [log](/) to view the message, open the [log view](/).

The script will not be executed and will either switching the editor to control surface mode, or the run button is pressed.

Use the right arrow (here is a button to maximize the editor and hit the area of the panel on the right for easier setting of longer scripts.

Summary

A short summary of the error message after compiling the script source.

Log

Open the application's [log view](/) and show the script messages page.

Find/Replace

Toggle the editor's find/replace tools.

For selecting operating systems the standard keyboard shortcuts for find/replace can also be used to show those tools.

Run

Compile and execute the script code immediately.

Script code is automatically compiled and executed on every control, every time the last editor causes input focus, and as the user types in the editor. Use this button to force the script to be executed.

The run button will compile and execute the script code **immediately**, making it possible to test and run scripts in the editor without switching to control surface mode.

Control's Panel

Editor - Network

The layout and connection network feature shows the interaction of the [application's](/) set of controls, [layout](/) of the network and lets multiple other instances on the network connect as [clients](/).

The editor screen will be switched into control surface mode and will not be available for [control set](/) editing.

The editor controls will be locked into control surface mode and will not be available for [control set](/) editing. Use the [connections](/) tab to connect to other TouchOSC instances.

Connected clients will be able to view the control surface with all messages and access fully functional [connections](/connections) to the host's [control set](/) and [layout](/). Clients will not be able to edit the control set.

NOTE that the control set is stored in [device memory](/) and not in the [document](/) **once either the [editor enabled](/) or [connected](/) to a host**. Any changes to the control set will be lost when the application is closed or restarted. Use the [document](/) feature to export the control set to a file.

- Clients
  - Manual Connect
  - Available Servers
- Network
  - Protocol

Client

Manual Connect

Enter an editor server IP address or host name and port number manually to connect. The app's Bonjour port number and the application's default port number for editor servers.

Available Servers

The list of available servers with the payload with [document](/) name that have the [server](/) option enabled.

The TouchOSC supports the configuration-embedding [language](/) to discover editor servers available on the local network. Use the list to select and join the [Unicast mode](/) editor to connect to an editor server.

Discovered editor hosts will be displayed with host name and a connect button to initiate the connection to the selected editor.

If an editor server host is inaccessible on multiple networks interfaces or IP addresses, it will be displayed by separate device device of the possible IP addresses to connect to and allow connection via each interface.

Server

Enabled

Enables the editor network's server portion to listen for incoming client connections.

Only one TouchOSC instance can be configured as a server on the network. Connected applications uses. We might settings for assistance in the host and address security measures.

Network's Panel

Connections

TouchOSC supports multiple connection types for [messages](/) to be sent and received on.

Each type of connection can have between 1 to 32 connections for each sequence, simultaneous connections configured and used with mixed and send and receive.

Each of these individual connections can be enabled individually for a [messages's configuration](/).

- MIDI
- OSC
- Bridge
- Websocket

MIDI

MIDI connections can be used for sending and receiving messages according to the [MIDI 1.0 protocol specification](https://www.midi.org/specifications/item/the-complete-midi-1-0-detailed-specification).

MIDI connections can be used to send and receive MIDI [messages](/messages) and [values](/values).

MIDI connections can be used to send and receive MIDI [messages](/messages) and [values](/values).

See the section on [MIDI connections](#) configuration for details.

OSC ▸

OSC connections can be used for sending and receiving messages according to the [Open Sound Control](#) protocol.

See the section on [OSC connections](#) configuration for details.

Bridge ▸

Bridge connections act as a host AND a local point that maintain MIDI messages over the network to and from a client on the same network running the [Gamepad](#) app on a mobile device.

Its also common to see a connection to a service or the TouchOSC Bridge application using a USB cable.

Each of these configured connections can be enabled/disabled as long as and output ports in the [MIDI connections](#) configuration.

See the section on [Bridge connections](#) configuration for details.

Gamepad ▸

Gamepad connections allow receiving input from connected game controllers.

See the section on [Gamepad connections](#) configuration for details.

Connections - MIDI

TouchOSC allows to configure two separate MIDI connections, each with freely assignable input and output ports. Each of these connections can be individually enabled for control via [MIDI messages](#) and sent and received to.

All enabled TouchOSC Bridge connections can also be configured here on input and output ports just like regular MIDI devices. Note that TouchOSC Bridge supports the full range of MIDI messages over the network or cable.

Currently, iOS and Android operating systems have no API for MIDI functionality at the top of this page, to switch to the TouchOSC Bridge connection configuration and then, and to open the configuration dialog for Android MIDI.

- Enable
- Expand
- Network Port
- Browse

Enable ▸

The checkbox at the top left toggles the enabled state of the connection. If a connection is not enabled it will not send or receive any messages.

Expand ▸

The arrow button to the right toggles the display between visible details sections of the connection and a short, read-only summary.

Send Port ▸

The number of the MIDI output port to send messages to. This can be any name you enter into the text field or an item selected from the list of the system ports in the [Browse](#) menu.

If you leave this field empty or its MIDI input port by the specified name is found at runtime, no messages will be sent.

Receive Port ▸

The name of the MIDI input port to receive messages from. This can be any name you enter into the text field or an item selected from the list of the system ports in the [Browse](#) menu.

If you leave this field empty or its MIDI input port by the specified name is found at runtime, no messages will be received.

Browse ▸

The browse button will list all sending input and output ports currently found on the system, as well as all enabled TouchOSC Bridge connections for selection. Both lists are updated in real time and will show up to ports added after displaying.

Connections - OSC

TouchOSC allows to configure two separate OSC connections, each with freely assignable send destination and receive port. These OSC connections can be individually enabled for control via [OSC messages](#) and sent and received to.

Each connection receive port can also be altered live in the network using the Zero Configuration Networking [Bonjour](#) API, enabled for other OSC-enabled applications and devices to discover.

- Enable
- Expand
- Type
- Host
- Send Port
- Receive Port
- Network Info
- Browse

Enable ▸

The checkbox at the top left toggles the enabled state of the connection. If a connection is not enabled it will not send or receive any messages.

Expand ▸

The arrow button to the top right toggles the display between visible details of the connection and a short, read-only summary.

Type ▸

The type of OSC connection to establish. TouchOSC supports three connection types to transport OSC messages on:

- **UDP**
  The UDP connection
  The user datagram protocol (UDP) is the most commonly used OSC protocol. It is connectionless and stateless, and as you unsure which type of connection to choose, it is highly likely that this is the correct one.
- **TCP Client**
  A TCP client connection to another host
  The TCP protocol is connection-oriented and provides additional functionality for no-connect connections.
- **TCP Server**
  A TCP server connection other clients can connect to.

When using one of the TCP/IP connection types, the **Framing** option will become available to choose one of the following message framing methods:

- **OSC 1.0**
  Use OSC 1.0 to apply the simple message framing scheme (size count+ preamble) suggested by the [OSC 1.0 specification](#).
  The amount should begin with an int32 giving the size of the first packet, followed by the contents of the first packet, followed by the size of the second packet, etc.
- **OSC 1.1**
  Use OSC 1.1 to use the SLIP (IETF/RFC 1055 double END character encoding as required by the [OSC 1.1 specification](#).

Host ▸

For the connection types **UDP** and **TCP Client** a host name or IP address can be entered as the destination for sent messages. To browse for other applications and devices that advertise their OSC existence of the selected connection, see the [Network Info](#) section.

If you leave this field empty or the destination host is not found at runtime, no messages will be sent.

Send Port ▸

For the connection types **UDP** and **TCP Client** a port number can be entered as the destination for sent messages. To browse for other applications and devices that advertise their OSC existence of the selected connection, see the [Network Info](#) section.

If you leave this field empty no messages will be sent.

Receive Port ▸

For the connection types **UDP** and **TCP Server** a port number can be entered to listen for received messages at client connections respectively.

If you leave this field empty no messages will be received.

Network Info ▸

The small info icon next to the [Receive Port](#) input field will open a dialog listing all IP addresses of all available and active network interfaces on the system.

Additionally all hosts and IPs addresses are shown, to which the application has advertised its **Bonjour Port** interface.

To refresh the list manually, click the **Refresh** button to update the list.

Zeroconf ▸

If the [Type](#) field has been set a value, the option to advertise the connection's OSC receiver on the network using the [Bonjour](#) API is shown that becomes available with the following options:

- **Disabled**
  Disable Bonjour advertising of the connection's OSC receiver on the network.
- **Default**
  The application will use the local name of the device for advertising the connection's OSC receiver on the network.
- **Custom**
  Use a custom service name for advertising the connection's OSC receiver on the network.
- **Local Port**
  Use the local OSC Port number for advertising the connection's OSC receiver on the network for use with the included Local Port record.

Browse ▸

The browse button next to each connection's [Host](#) field will list all OSC receivers compatible with the connection's type that on the network using the [Bonjour](#) protocol.

Selecting any of the available results will fill in both the **Host** and **Send Port** fields for the connection. In case the selected receiver is found to be running on the local device, the **Host** field will be set to 127.0.0.1 and the **Send Port** field to the local name for external advertising.

The list of results is updated in real time and will show any additional receivers discovered while displaying.

Connections - Bridge

TouchOSC allows to configure two separate connections to connect to instances of the TouchOSC Bridge application.

TouchOSC Bridge acts as a virtual MIDI interface, transparently transmitting MIDI messages to and from another device on the network or using a USB cable to a device connected to the system.

Each enabled Bridge connection can be individually selected as MIDI input and output port in the [MIDI connections](#) configuration.

- Enable
- Expand
- Browse



Enable ▸

The checkbox at the top left toggles the enabled state of the connection. If a connection is not enabled it will not send or receive any messages.

Host ▸

Enter a host name or IP address of the device running TouchOSC Bridge. To browse for available TouchOSC Bridge instances on the network, see the [Browse](#) section.

The reserved connection name **USB** can be used on iOS devices to connect to a TouchOSC Bridge instance running on a computer connected using a USB cable.

If you leave this field empty no messages will be sent or received.

Browse ▸

The browse button next to each connection's [Host](#) field will list all TouchOSC Bridge instances found on the network.

On iOS devices, an additional **USB** connection will be available to connect to a TouchOSC Bridge instance running on a computer connected using a USB cable.

The list of results is updated in real time and will show any additional instances discovered while displaying.

Connections - Gamepad

TouchOSC allows configuring two connections to receive input from connected game controllers. Each of these connections can be enabled for control in [Gamepad messages](#) to receive input from.

- Enable
- Expand
- Browse

Enable ▸

The checkbox at the top left toggles the enabled state of the connection. If a connection is not enabled it will not receive any input.

Controller ▸

The name of the game controller to receive input from. Choose any of the currently connected game controllers from the list that appears when clicking the field.

The configured controller can be accessed from the [Gamepad](#) tag in the control.

The configured controller's GUID will be saved to the configuration between application runs or when the selected controller is disconnected and back on connect.

Browse ▸

The browse button will list all connected game controllers currently found on the system. The list will be updated in real time and will show any controllers added or removed while displaying.

Preferences - General

- User Interface scale
- Theme
- When connections affect stability
- Show comments after loading ▸
- Enable debug logging

User interface scale ▸

Enable scaling factor for all of TouchOSC's user interface. Needs a restart of the application to be applied.

Note: This is an experimental feature and maybe cause some user interface elements to behave or render incorrectly.

Updates ▸

Automatically retrieve the latest version to check for an updated version of the application on startup, on most platforms.

The **Channel** menu allows for selecting either the "Stable" or "Beta" update channels. Please note that beta releases are only preceding upcoming future releases under development and may contain bugs or issues and might not be ready for everyday use at your own risk.

The **Check now** button will manually check for a new version, operating system type and architecture will be determined from the website during the check.

Show comments after loading ▸

If a document has the value for the "Creator" or "Comments" document properties, display those after loading has finished.

Send anonymous usage statistics ▸

The enable sending of anonymous usage statistics to help improve to the feature set website.

This does include data about your system and use of the application, such as operating system, version and language. Hardware specifics such as amount of RAM and total number of CPU cores, type of GPU graphics card are collected.

We use the anonymous data to determine the future direction of the application's design and the stability of current support for new popular hardware software configurations. Therefore we strongly recommend leaving this option enabled to help us improve TouchOSC for everyone.

For more information see our Privacy Policy.

Enable debug logging ▸

This will cause the application to log a much larger amount of information about its internal operations.

Note: This will result in many more superfluous processes and data stored, and in any bug encouraged when saved to the log out of our developers to support staff and why while diagnosing problems.

The **Show logs** button will open the operating system's file browser at the location of the TouchOSC's log files.

Preferences - Editor

- Appearance ▸
  - Show Grid
  - Snap to Grid
  - Show Rulers
- Behaviour ▸
  - Create default MIDI messages
  - Create default OSC messages
  - Assign new notes on new layers
  - Toggle navigation only with ALT key
- Script ▸
  - Font Size
  - Word Wrap
  - Code Highlighting
  - Code Completion

Appearance ▾

Show Grid

Toggle the rendering of a grid in the background of the editing surface and configure spacing, appearance and color.

Snap to Grid

Toggle whether controls will snap to the widths and other being positioned.

Show Rulers

Toggle the rendering of rulers at the top and left edges of the editing surface.

Behaviour ▾

Create default MIDI messages

When creating a new control, automatically create and configure a suitable MIDI message as well.

Create default OSC messages

When creating a new control, automatically create and configure a suitable OSC message as well.

Assign new notes on new layers

When copy/pasting a control, automatically assign a new name to the control.

Toggle navigation only with ALT key

Prevent accidentally moving controls when navigation is enabled by default and allows to switch between navigation and edit mode in which controls can be moved. This option enables this behavior only when the ALT key is held down while navigating.

Note: This option is only available on desktop platforms.

Script ▾

Font Size

Font size used by the script editor.

Word Wrap

Enables word wrapping in the script editor.

Code Highlighting

Enables/ passed code highlighting in the script editor.

Code Completion

Enables code completion in the script editor.

Preferences - Control Surface

- Display ▸
  - Orientation
  - Allow sleep
  - Show Index
- Back Button
  - Enable
  - Position
  - Horizontal

Display ▾

Orientation

Determine the interface orientation that the control surface will be rendered with.

NOTE: In the default and auto render the control surface the same as processed in the editor.

NOTE: On some the orientation is to be automatically chosen to maximize the space the control surface will occupy considering the available device screen size and orientation.

NOTE: On some platforms, such as iOS, the application's orientation is restricted and predetermined in any way. Please see your device's interface settings for these settings to understand with the application's setting to achieve the control's intended behaviour for your setup.

Allow sleep

Allow the device to sleep when in control surface mode.

The default is to keep the device and display on at all times when in control surface mode.

NOTE: The setting is only available on mobile devices.

Padding ▾

Configure the amount of space to reserve at the top, bottom, left and right edges of the screen when rendering the control surface layout.

Back Button ▾

Options to control the back button for exiting the control surface view and returning to the settings view.

Device type

Select the device type to configure the position of the back button for.

Enable

Toggle the rendering of the back button.

Position

Select the position of the back button.

Horizontal

Select the horizontal position of the back button.

Vertical

Configure the vertical alignment of the task button.

Horizontal

Configure the horizontal alignment of the task button.

Preferences - Script

- Timeout
- Invalid API Usage

Timeout +

A control's Python mode, long running scripts will be terminated to prevent the application from stalling.

- **SHORT**
  The default setting, any one script is allowed to take up to ~200ms.
- **LONG**
  Use when devices running complex layouts it might be helpful to extend the timeout to ~2000ms. Please use this setting with caution and only if absolutely necessary.

NOTE that in edition mode, the timeout will always be longer than either of these settings to allow for long running, multi-frame script executions while developing.

Invalid API Usage +

When invalid API usage is detected (e.g. accessing non-existent control properties or values), or calling API functions with incorrect arguments the following action will be taken:

- **LOGGER**
  Will log the error to a file and an error message will be printed to the SCRIPTING log and the script will be stopped.
- **SHARE**
  Will log the error to a file in terminal mode and will be printed to the SCRIPTING log and the script will continue to execute. If the API call is a getter request a default value is returned, or an error will be returned.
- **IGNORE**
  Will silently fail and print to the SCRIPTING log and the script will continue to execute. If the API call is a getter request a default value is returned, or an error will be returned.

Inherited Section

Preferences - Log View

- Font Size
- Font Name
- Timestamp
- Keep log lines
- Control name as path
- Open in separate window

Font Size +

Font size used by the log view.

Keep log lines +

Number of log lines to keep in the scroll back history.

Note: Setting this option to a large value may drastically impact performance.

Display +

Timestamps

Display a timestamp for each logged event.

Control name as path

Display a control's as a path, with all parent container names separated by a forward slash.

Open in separate window

Open the log view in a separate window instead of a split view embedded in the main application window.

Inherited Section

Preferences - Import

Options that apply to the import of .msmacro files.

The exported .Net methods some OSC messages that are either unaddressed globally in the application's OSC options or expressed only available for all controls. To provide maximum compatibility some of the following preferences offer the option to generate these messages automatically on import.

- Application
- Apply Control State
- Global OSC Messages
  - Ping
  - Autoincrement
  - Position
- Control OSC Messages
  - Touch
  - Visibility
  - Position
  - Size
  - Color

Appearance +

Apply Custom Style

This option will configure the properties of all imported controls to closely resemble the look of the original control rendering of the TouchOSC Mk1 app.

Global OSC Messages +

Ping

If enabled, with each control a /ctrl/guid/ping message is sent to periodically send a /sync OSC message of all configured OSC connections.

Note: to be globally configured value for the delay of this message can not be read from the TouchOSC Mk1 app's preferences, please see the original value at the document level to manually change this value.

Autoincrement

If enabled, with each control a /ctrl/guid/autoincrement message is sent to /sync OSC message with three float arguments to increment the first decimal separated number between 0 and 1 of all configured OSC connections on each control.

Velocity

If enabled, with each control a /ctrl/guid/velocity message is sent to /sync OSC message with three float arguments to send the velocity of the control in x/y/z coordinates.

Control OSC Messages +

Touch

If enabled, with each control a /ctrl/guid/touch [1|0] OSC message to be generated that will send when the control's touch state changes.

Visibility

If enabled, with each control a /ctrl/guid/visible [1|0] OSC message to be generated that will send when the control's visibility state changes.

Position

If enabled, with each control a /ctrl/guid/position [x|y] OSC message to be generated that will send when the control's position changes.

Size

If enabled, with each control a /ctrl/guid/size [x|y] OSC message to be generated that will send when the control's size changes.

Color

If enabled, with each control a /ctrl/guid/color [r|g|b|a] OSC message to be generated that will send when the control's color changes.

Control Key Messages +

Convert to OSC messages

If enabled, all control of any messages found in the source import to OSC messages.

These messages will be in the same format the TouchOSC Bridge expects, and therefore can be used to trigger the same actions as configured in the TouchOSC Bridge app.

Preferences - MIDI

- General
  - Apply MIDI CC message velocity
- Virtual Ports
  - Create MIDI input
  - Create MIDI output

General +

Feed NOTE OFF message velocity

If enabled will forward all received NOTE OFF message velocity values unmodified. Otherwise, NOTE OFF message velocity values will be automatically set to zero.

Virtual Ports +

NOTE: These options are currently not available on Android.

Create MIDI input

Determine the creation of a virtual MIDI input port named 'touchMIDI'.

Create MIDI output

Determine the creation of a virtual MIDI output port named 'touchMIDI'.

Inherited Section

Control Reference

In this section we describe all properties and values that are specific to each control.Use the colored bar at the top of each control to quickly find the control you are looking for. Controls are listed in alphabetical order.

All properties and values can also be accessed from within scripts. Please see the scripting API Properties & Values section for information about the field names and types to use for script access.

- BOX
- BUTTON
- LABEL
- TEXT
- FADER
- XY
- RADIAL
- ENCODER
- RADAR
- RADIO
- PAGER
- GRID
- SPACE

BOX +

A box control is a simple shape with no behavior. It is meant to be a fill element to make for creating decorative elements and backgrounds or to be nested and combined with other controls.

Properties

Name	Description
Shape	The shape of the control

Values

Name	Type	Description
Shape		The shape of the control

BUTTON +

A control button control with properties to control the press/release behavior. As in case of LUA value the its history is can be also used as a simple LUA display.

Properties

Name	Description
Shape	The shape of the control
Type	The type of control • **Momentary** - [Default button] • **Toggle** - Toggle button, value is flipped on release • **Toggle Press** - A toggle button, trigger on press
Press	Enable the press event for this button.
Release	Enable the release event for this button.
Value Follow	If this property is set to true the button will use the position of the scanner event to calculate its value. Else the control will take the value of the [Increment](#) property in this account.

Values

Name	Type	Description
x	FLOAT	The amount of 'pressure' on the button from fully released to fully pressed. The button will be released when the value equals exactly to the value of the button.

LABEL +

A simple text field display.

Properties

Name	Description
Font	The typeface for rendering the text • **DEFAULT** - The default, scalable system font • **PIXELPERFECT** - A monospaced, fixed width font
Size	The font size.
Length	The maximum length of the text.
Alignment	Horizontal and vertical alignment of the text inside the control.
Clip	Controls the clipping of the rendered text to the control's frame **Note** that disabling this property can significantly improve rendering performance in certain cases.
Wrap	Controls the word wrapping of the rendered text to the control's frame.

Values

Name	Type	Description
text	STRING	The display text.

TEXT +

A multi-line text display.

Properties

Name	Description
Font	The typeface for rendering the text • **DEFAULT** - The default, scalable system font • **PIXELPERFECT** - A monospaced, fixed width font
Size	The font size.
Color	The text color.
Clip	Controls the clipping of the rendered text to the control's frame **Note** that disabling this property can significantly improve rendering performance in certain cases.
Wrap	Controls the word wrapping of the rendered text to the control's frame.

Values

Name	Type	Description
text	STRING	The display text.

FADER +

A fader control.

Properties

Name	Description
Curved	Shows a curve. • **ALWAYS** - Shows always • **ACTIVE** - Shows only if any active pointers • **INACTIVE** - Shows only if no active pointers
Bar	Shows a bar. • **ALWAYS** - Shows always • **ACTIVE** - Shows only if any active pointers • **INACTIVE** - Shows only if no active pointers
Centered	Render the value bar from the center.
Response	Type of response to pointer input • **ABSOLUTE** - Jump to pointer position • **RELATIVE** - Change relative to pointer position
Pointer	Response factor for relative response, or percent of pointer position change.
Grid	Render grid lines and the number of grid lines to render.
Grid Color	The grid line color.

Values

Name	Type	Description
x	FLOAT	The value position.

XY +

A two-dimensional fader control.

Properties

Name	Description
Curved	Shows a curve. • **ALWAYS** - Shows always • **ACTIVE** - Shows only if any active pointers • **INACTIVE** - Shows only if no active pointers
Lines	Shows axes lines. • **ALWAYS** - Shows always • **ACTIVE** - Shows only if any active pointers • **INACTIVE** - Shows only if no active pointers
Lock X	Lock the x value for pointer input. The value can still be changed through messages and script.
Lock Y	Lock the y value for pointer input. The value can still be changed through messages and script.
Response	Type of response to pointer input • **ABSOLUTE** - Jump to pointer position • **RELATIVE** - Change relative to pointer position
Factor	Response factor for relative response, or percent of pointer position change.
Grid	Render grid lines and the number of grid lines to render.
Grid Color	The grid line color.

Values

Name	Type	Description
x	FLOAT	The x value position.
y	FLOAT	The y value position.

RADIAL +

A circular radial control.

Properties

Name	Description
Inverted	Reverse the value range.
Centered	Displays the value from the center of the value range.
Response	Type of response to pointer input • **ABSOLUTE** - Jump to pointer position • **RELATIVE** - Change relative to pointer position
Factor	Response factor for relative response, or percent of pointer position change.
Grid	Render grid lines and the number of grid lines to render.
Grid Color	The grid line color.

Values

Name	Type	Description
x	FLOAT	The value position.

ENCODER +

A circular encoder control.

Properties

Name	Description
Curved	Shows a curve. • **ALWAYS** - Shows always • **ACTIVE** - Shows only if any active pointers • **INACTIVE** - Shows only if no active pointers
Response	Type of response to pointer input • **ABSOLUTE** - Jump to pointer position • **RELATIVE** - Change relative to pointer position
Factor	Response factor for relative response, or percent of pointer position change.
Grid	Render grid lines and the number of grid lines to render.
Grid Color	The grid line color.

Values

Name	Type	Description
x	FLOAT	The value position.
y	FLOAT	The direction of change of the value position.

RADAR +

A circular XY control, measuring distance from center and angle.

Properties

Name	Description
Lines	Shows axes lines. • **ALWAYS** - Shows always • **ACTIVE** - Shows only if any active pointers • **INACTIVE** - Shows only if no active pointers
Lock X	Lock the x value for pointer input. The value can still be changed through messages and script.
Lock Y	Lock the y value for pointer input. The value can still be changed through messages and script.
Grid X	Render grid lines for distance and the number of grid lines to render.
Grid Y	Render grid lines for angle and the number of grid lines to render.
Grid Color	The grid line color.

Values

Name	Type	Description
x	FLOAT	The distance from the center.
y	FLOAT	The angle. The coordinate start with the value at the [Orientation](#) property into account.

RADIO +

A single value selection from a number of discrete values.

Properties

Name	Description
Steps	The number of discrete values.
Type	The type of change • **Select** - Highlight only the active value • **Move** - Highlight as slider as in the active one.

Values

Name	Type	Description

x	INTEGER		The vertical value.

GROUP

A simple container for child controls. A group can be a container of group child controls("page") and will display only the controls are based on its **page** value. A page control can be emphasized to behave like individual page group elements.

Properties

Name	Description
Text	Displays the page's tab text.
Box Size	The size of the page's tab box.
Double Tap	Require a double tap on the tab bar instead of a single press to change the active page.
Locks	Displays the state of each child page's **Lock** property on the tab bar.
Tint Color	Tint color for labels on the tab bar for each inactive page selector and the active page label.

Page Properties

Name	Description
Name	The name of the child group control.
Label	The text to display on the parent page's tab bar for this page.
Background	The background color of this page group control.
Tint Color	Tint color to use for this parent page's tab bar button for this page, for both active and inactive states.
Text Color	Tint color to use for this parent page's tab bar button label for this page, for both active and inactive states.

Values

Name	Type	Description
page	INTEGER	The active page index.

GRID

A container for a two-dimensional, uniform grid of child controls of the same type. A grid control can be emphasized to behave like individual child controls. The editor also display the child controls' typed properties in addition to the grid control's own properties.

Properties

Name	Description
Type	The type of child controls.
X	The number of columns in the grid.
Y	The number of rows in the grid.
Size	The number of the grid's child controls creating the child controls.
Order	The direction in which to proceed first in the grid when creating the child controls.
Naming	The value to use when assigning the **Name** property of the created child controls.
Automate	Determines whether control value changes, each of the child controls' values of the same name will be automated.

Setup Examples

Examples, instructions and recipes on how to set up TouchOSC with other applications and hardware.

We'll be adding more of these in the future, so please check back again at a later time.

Getting Started

- Protokol | MIDI
- Protokol | OSC
- Ableton Live

How-to's

- Android USB MIDI
- Android Wi-Fi MIDI
- Bitwig Studio
- Bome's MIDI Translator
- Logic Pro

Setup - Android USB MIDI

Beginning with the Android 6 (Marshmallow) release, device makers can enable optional MIDI support in the platform.

If your device manufacturer added support for the **USB peripheral mode**, please follow these steps to enable it and use TouchOSC with USB MIDI. If you're not sure or the USB data connection setup above TouchOSC on their own to send and receive MIDI messages:

- Device Setup
- TouchOSC Setup
- Send MIDI messages

Device Setup

While attached to a USB host, pull down from the top of screen and select the device's **USB tile** ... or similar. The exact wording and depend on the customizations applied by your device manufacturer.

From the list of options that appear, select **MIDI** or similar. Again, the exact wording will depend on the customizations applied by your device manufacturer.

Alternatively these options can also be found in the Android Developer Options in **Settings > Developer options > Networking > Select USB Configuration**.

TouchOSC Setup

By enabling the **USB peripheral mode** on your Android device, the OS will also create MIDI input and output ports for TouchOSC. Check that **Enable** and **Send Feedback** are enabled in the **Connections > MIDI** settings.

In TouchOSC's MIDI connections configuration screen the newly created **Android USB Peripheral Port** (or similar) for both the **Send Port** and **Receive Port** lists.

Lastly, again, the exact naming of these ports will depend on the customizations applied by your device manufacturer.

Send MIDI messages

We'll use the Protokol application to confirm that the MIDI ports are visible to our USB host and that we can receive MIDI messages sent from TouchOSC.

Protokol is our free tool for testing OSC and MIDI connections and messages. This is the ports utility we use in the following steps to confirm that MIDI messages are received.

Launch the Protokol application, switch to the **MIDI** tab page, and check the checkbox next to **Enabled**.

If all went well, you should see a connected MIDI interface in Protokol that is named primarily to your device, and should also include the name of the USB port you selected in the Android USB settings above.

As you might have guessed, the exact names of the MIDI ports that your device creates depend on the customizations applied by your device manufacturer.

Setup - Resolume Wire

Resolume Wire is a modular node-based patching environment to create effects, mixers and video generators for Resolume Arena & Avenue.

Wire supports both MIDI and OSC control, but as OSC is the more flexible of the two and can be used both locally and over a network, we'll create through mapping OSC control from TouchOSC into your Wire project.

- Enable OSC Input
- Configure TouchOSC
- Create OSC nodes
- Print OSC messages

Enable OSC Input

Open the **Wire** preferences, switch to the **OSC** section on the left and enable the **OSC Input**.

Wire is now listening for incoming OSC messages on the **IP Address** and **Incoming Port** number displayed here.

Configure TouchOSC

Open **TouchOSC** and make sure that you are connected to the same network as the machine that is running **Wire**.

⚠ If you are running the Windows operating system and choose to connect via a networked connection, please make sure the Windows firewall is not preventing data being sent between TouchOSC and Wire. For more problems, please disable the Windows firewall temporarily and try again.

Open TouchOSC's **OSC connection settings**.

Make sure **Connection** is enabled and set to type **UDP**.

Use the **Browse** button to search for and select Wire's OSC input on the network and fill in the required values automatically.

If the Wire instance cannot be found, manually fill in the **IP Address** displayed in Wire's OSC preferences in the **Host** field, and the **Incoming Port** number into the **Send Port** field.

Close the connection pane and document configuration to send OSC messages, such as the included example layout **Simple Mix1**.

Switch to control surface mode using the **Play** button in the toolbar.

Send a few OSC messages from TouchOSC to Wire by using any of the controls in the layout.

In Wire, expand the OSC Input by pressing the button with the arrow pointing to the right in the top right corner of the OSC preferences.

If everything is working, you should see the OSC messages sent from TouchOSC in Wire appear in the OSC Input log and the input configuration is complete.

Create OSC nodes

Create a new Wire project and double-click on the empty project's background to open the node search window.

Enter **OSC** to filter all nodes related to OSC communication.

Select **OSC Rx** to create an OSC input node.

Open the node search window again and create a **Read OSC** node.

Connect the output of the **OSC Rx** node to the input of the **Read OSC** node.

In the **Read OSC** select **Address** field, enter the OSC address that you want to receive.

If you've opened the **Simple Mix1** layout in the previous steps, enter /1/fader1.

Open the node search window once again, search for **grid** and create a **Print** node.

Connect the **Focus** function of the **Head OSC** node to the input of the **Print** node.

With this setup, the value of the first parameter of OSC messages with OSC address /x/foo/x sent to Wire will be printed in the **log**.

If you've opened the **Simple PAD** layout in the previous steps, this will be a floating point value ranging from 0 to 1.0.

Print OSC messages +

With both the setup of TouchOSC and Wire now complete, let's open the **Log** view in Wire and confirm that the values are being printed.

The **Log** view in Wire can be found in the **Log** tab in the upper-to-the-right of the window.



Some OSC messages from TouchOSC for using the fader control pictured below and you should see the received values printed in the **Log** view in **Wire**.



Starting with the basic patch, it should be easy to see the values received from TouchOSC in your own compositions and visual effects.

Happy patching!

Last updated 2 months ago

Setup - Steam Deck

Follow these steps to download, install and run TouchOSC on the Steam Deck



- Switch to Desktop Mode
- Download TouchOSC
- Extract TouchOSC
- Launch TouchOSC

Switch to Desktop Mode +

Open the **Steam Menu** using the **Steam Button** and select **Power**



And in the following dialog select **Switch to Desktop**.



The Steam Deck will now switch to **Desktop Mode**.



Download TouchOSC +

Start the **Firefox web browser** from the task bar at the bottom and navigate to the TouchOSC download section hosted at https://hexler.net/touchosc#linux.

On the **Desktop** section of the downloads, click the button named **LINUX**

A pop-up dialog with all available versions for Linux will appear. Click the button labelled **AM** in the section **x64** 1

The tar.gz file will be downloaded to your **Downloads** folder.

Open the **Dolphin** file browser from the task bar at the bottom for the downloads menu in Firefox and select **Downloads** in the list of **Places** on the left.



Extract TouchOSC +

In the file browser **double-click or tap the downloaded zip file** and the archiving tool will launch and display the contents of the zip archive.

Select the first item, **TouchOSC** which has the **Extract** button in the top-left.

In the dialog that appears, leave as-is and to change anything, just click **Extract** again to unpack the TouchOSC executable to your **Downloads** folder.

Launch TouchOSC +

Back in the **Downloads** folder in the file browser there is now a new file named **TouchOSC**

Double-click or tap the file.

In the dialog presented, **Run it or do you wish to do edit this file?** choose **Execute**.

The application should launch and the main TouchOSC window should appear - similar to what is **portable-sserial** mentioned earlier.

If you see now is the TouchOSC window, have a look at our Getting Started guide.

If you are running into any problems following these steps, please do not hesitate to contact us with us and we can assist!

Setup - Traktor

For the next generation of TouchOSC, Traktor wizard Jochem Bezuur has created the follow up to his legendary App for Users.

App for it's the essential control surface for Native Instruments' Traktor Pro software and it's included with TouchOSC and Hexler.pro.

Downloads

Download the dedicated manual and Traktor setup file below. The layout itself is included with the application on all platforms.

PDF MANUAL PRESETS

Updates

v2.1 - On May 2024,

- Mixer Section, sorry, this is PT-centric for all four individual Mixer Tracks can now be controlled together with the Master Section. Also, Mixer Section is now Mixer Tracks.
- Added volume level meters for each individual Deck Track.
- Added Loop Recorder Indicator and Decks now display Remain/Left, all volume meters rather than L/R summed to Mono.
- Added volume level meters on all Decks now display 'warning' colour change when volume level approaches zero.

v2.0 - On Jun 2021

- Complete redesign of the original App for Session Pro MIDI.

Videos

A detailed set of videos by Andrew demonstrating and explaining the inner workings of the layout.

Last updated 2 months ago

Setup - Logic Pro

Minimum required versions

- Logic Pro 10.5 or higher

Note: Make sure your computer and all mobile devices are on the same wireless network.

Adding TouchOSC as Control Surface in Logic

- Start Logic if it's not open.
- Open TouchOSC and configure an OSC Connection as follows:
  - Enable **Bonjour** and **Auto Connect**
  - Enable the **Browser** button and select the name of the computer running Logic. The **Host** and **Send Port** fields should now be filled in.
  - Set the **Receive Port** to the **Receive Port** field for TMD.
  - Set the **Network** option to **Layer/Fader + Layer/Knob**, depending on which of these two layouts you plan to use.
  - Close **Done** to apply the connections settings.
- Logic will display the following alert:

- Close the **Add** button. Logic will add the device as a control surface and open the Control Surfaces Setup window.

Note: If you share the wireless network with other Logic systems, you may want to select the **Don't show again** option, to avoid getting this alert every time TouchOSC starts. This will prevent the listing of any remaining instances, which saves valuable screen space. You can reset this alert suppression by re-enabling **Note > Automatic Installation** in the Control Surfaces Setup window.

Note: If the macOS software firewall is enabled, an alert will come up when sending the first OSC message. You will need to confirm that the Logic app can communicate with the OSC device.

Note: It is not possible at this time to use customized playlists or to have OSC commands. However, authorized DJ skins developed for Traktor and DJ.ming.one which use OSC based communication.

Last updated 2 months ago

Scripting API

TouchOSC's scripting API is based on the Lua 5.3 language and a virtual machine with custom additions and modifications.

Scripts can be used to add controls to a document and at the document root level. Each control's script will be executed in its own environment.

- Lua Functions
- Lua Extensions
- Globals

Version 2.0.0-beta

Script - Lua Functions

The following Lua standard library functions are available:

bone ⌂

Only the following Lua library functions are available:

```
load
pairs
ipairs
next
select
tostring
tonumber
```

string ⌂

All standard Lua string library functions are available.

table ⌂

All standard Lua table library functions are available plus the following additions:

```
table.count(t)
```

Returns a new sequence table created from the elements provided.

```
table.append(t, ...)
```

Same as the Lua table library function unpack.

math ⌂

All standard Lua math library functions are available plus the following additions:

```
math.round(num[, number_places])
```

Returns `num` rounded to `number_places` after it. If the first parameter `num` is not provided, the second parameter is ignored.

bit32 ⌂

Added in 2.0.0

Support for bitwise operations has been back-ported from Lua 5.2. All functions are available inside the table `bit32`.

utf8 ⌂

Added in 2.0.0

Support for UTF-8 encoding has been back-ported from Lua 5.3. All functions are available inside the table `utf8`.

Script - Global Functions

ThumbSIM provides the following global functions.

- Utility Functions
  - getVersion
  - getMenu
  - getMessage
  - findLocalInterface
  - findLocalAddress
  - hostIsInvalid
  - getMACAddress
  - getNetworkInterface
  - listenPort
- Message Functions
  - MIDI Messages
  - Simple OSC Messages
  - Complex OSC Messages
  - Bundled OSC Messages
- JSON Functions
  - encodeToJSON
  - decodeFromJSON

Utility Functions ⌂

```
function getVersion()
```

```
local version = getVersion()
print("ThumbSIM version: " .. version)
-- 2.0.0 (for a build named with 2.0.0)
```

Returns a text containing the application's version as `major.minor.patch.build` number.

```
function getMenu()
```

```
local menu = getMenu()
print("Menu: " .. menu)
-- Menu: Edit
```

Returns the number of interactive(!) menu item selected by the user.

```
function getMessage()
```

```
local msg = getMessage()
print("Message: " .. msg)
-- Message: Hello, world!
```

Returns a text with the current local time in hour:minute:second:hundredth format.

```
function findLocalInterface()
```

```
local ip = findLocalInterface()
print("Local IP: " .. ip)
-- Local IP: 192.168.1.42
```

Returns a text of the first local address provided as unicast/sender sender. Same as `findLocalAddress()`.

```
function findLocalAddress()
```

```
local ip = findLocalAddress()
print("Local IP: " .. ip)
-- Local IP: 192.168.1.42
```

Returns a text of the first local address provided as unicast sender. Same as `findLocalInterface()`.

```
function hostIsInvalid(host)
```

```
print("Host is invalid: " .. tostring(hostIsInvalid("192.168.1.42")))
-- Host is invalid: false
```

Returns a text of the number values that are sampled from the host device's accelerometer sensor. If no accelerometer sensor is available, the values will be all zero.

```
function getMACAddress()
```

```
local mac = getMACAddress()
print("MAC: " .. mac)
-- MAC: 00:00:00:00:00:00
```

Returns the current battery charge level as a number ranging from 0 and 1, or 0 on mobile devices, is all-in-one.

```
function getNetworkInterface(name, number, address)
```

```
local ip = getNetworkInterface("en0", "ipv4", "address")
print("IP: " .. ip)
-- IP: 192.168.1.42
```

Returns a number that is the 32 bit integer representation created from the four byte number parameter values given.

```
function listenPort(protocol, number, timeout, handler)
```

```
listenPort("udp", 8000, 0, function(msg, sender)
  print("Received: " .. msg)
end)
```

Returns a number that is the 32 bit integer representation created from the four byte number parameter values.

```
function ipToInt(a, b, c, d)
```

```
local ip = ipToInt(192, 168, 1, 42)
print("IP: " .. ip)
-- IP: 3232235818
```

On devices that support it a short vibration will be triggered. Has no effect otherwise.

Version 2.0.0-RC

Message Functions ⌂

ThumbSIM provides the following functions to send MIDI and OSC messages.

MIDI Messages ⌂

```
function sendMIDI(bytes, number, timeout)
```

```
sendMIDI(0x90, 0x3C, 0x7F)
sendMIDI({0x90, 0x3C, 0x7F}, 2)
sendMIDI({0x90, 0x3C, 0x7F}, 2, 1000)
```

Send MIDI message to one or multiple configured endpoints.

The first argument `bytes` is a number or a table of bytes values that make up the MIDI message.

Starting with version 2.1.0, if the function will process byte data for multiple messages and continue until either the end of the table or a byte value that is not a valid MIDI status byte.

The optional second argument is a number or a list of numbers values that specify which connections to send the message. If this argument is omitted, the default is to broadcast the message on all configured connections. If the list has fewer elements than the number of connections, the remaining connections will be ignored.

For more usage examples see the Sending MIDI Messages example.

Simple OSC Messages ⌂

```
function sendOSC(address, {...}, number)
```

```
sendOSC("/ping")
sendOSC("/test", 1, 2.5, "hello")
sendOSC("/test", 1, 2.5, "hello", 2)
sendOSC("/test", 1, 2.5, "hello", {1, 2})
```

Send an OSC message on one or multiple configured connections.

`{...}` is the table of the OSC message to be sent.

The optional argument values are `nil` by default.

The optional argument `number` is a number or a list of numbers values that specify which connections to send the message. If this argument is omitted, the default is to broadcast the message on all configured connections. If the list has fewer elements than the number of connections, the remaining connections will be ignored.

Note that argument values are never auto-converted to integer. OSC types as scripts do not treat floating point and integer numbers as distinct types. See the [complex OSC messages example](#) for details.

The optional last argument is a list of hostname values that specify which connections to send the message. If this argument is omitted, the default is to broadcast the message on all configured connections. If the list has fewer elements than the number of connections, the remaining connections will be ignored.

For more usage examples see the Sending OSC Messages example.

Complex OSC Messages ⌂

```
function sendOSC(address, {...}, tables)
```

```
sendOSC("/test", {
  { 1, "hello", 2.5 },                    -- one
  { 2, "world", 3.5 },                    -- two
  { 3, "!", 4.5, { "nested", false } },   -- three
  { 4, "!", 5.5 },                        -- four
})
```

Send an OSC message on one or multiple configured connections.

The first argument `address` is a text that represents the OSC message to be sent. where the first element is the path string of the message, and the second element is a list of argument tables with tag and value pairs for each argument.

```
{
  { tag, value },
  { tag, value },
  { tag, { value, value } },
  { tag, value },
}
```

Each argument's tag can be left to `nil` to automatically assign a tag based on the value's type:

Tag	OSC Type
T	Boolean true
F	Boolean false
N	Nil
I	Infinitum
i	int32
h	int64
t	Time32
d	double
s	string
S	symbol
c	ASCII character
b	32 bit Midi Data
m	4 byte MIDI message
B	blob

If the tag value is omitted, the value will be auto-converted the same way as when sending simple OSC messages.

The third (`tables`) argument is a list of tables values that specify which connections to send the message. If this argument is omitted, the default is to broadcast the message on all configured connections. If the list has fewer elements than the number of connections, the remaining connections will be ignored.

For more usage examples see the Sending OSC Messages example.

Bundled OSC Messages ⌂

```
function sendOSCBundle(bundle {, tables})
```

```
sendOSCBundle({
  { "/test", { { 1, "hello", 2.5 } } },
  { "/test", { { 2, "world", 3.5 } } },
  { "/test", { { 3, "!", 4.5, { "nested", false } } } },
  { "/test", { { 4, "!", 5.5 } } },
})
```

Same as on how OSC messages as a bundle on one or multiple configured connections.

The first argument `bundle` is a list of one or more OSC messages to be sent. The messages are in the same format as the first argument of `sendOSC()`.

The optional second argument `tables` is a list of numbers values that specify which connections to send the message. If this argument is omitted, the default is to broadcast the message on all configured connections. If the list has fewer elements than the number of connections, the remaining connections will be ignored.

For more usage examples see the Sending OSC Messages example.

JSON Functions ⌂

ThumbSIM provides the following functions to convert Lua tables to and from JSON-encoded strings. All JSON functions are provided inside the global table `json`.

```
function json.encodeToJson(value)
```

```
local t = { 1, 2, 3, "a", "b", "c", { x = 1, y = 2 } }
local str = json.encodeToJson(t)
print(str)
-- [1,2,3,"a","b","c",{"x":1,"y":2}]
```

Convert a Lua table to a JSON-encoded string. The optional value `json.null` can be used to store a `null` value in the Lua table.

The input table should either be a sequential list of values, which will be converted to the JSON array type, or a list of key-value pairs, which will be converted to the JSON object type.

```
function json.decodeFromJson(text)
```

```
local t = json.decodeFromJson('{"a":1,"b":2,"c":3,"d":4,"e":5}')
print(t.a, t.b, t.c, t.d, t.e)
-- 1 2 3 4 5
```

Parse a JSON-encoded string and return the result as a Lua table. The JSON `null` value will be written to the output table as the special value `json.null`.

Script - Objects

ThumbSIM defines the following objects to represent its internal and native types:

- Control
- Interface
- Message
- Network
- Vertex

Script - Objects - Control

A control object represents a reference to a single control contained within a ThumbSIM document.

Using the reference most of a control's properties can be queried and set. From within a control's script, `self` is a reference to the control itself. From within a control's script, `parent` is a reference to the control's parent. Controls can be used to create hierarchies of controls.

Each control is assigned a unique ID number that remains unchanged during and between application runs, including when the document is saved and loaded.

All control's have a document, that is the top-level container of the document tree. All controls except for the root have a reference to a parent control, and some control types are considered the owner controls.

Storing a control reference value in a variable can be dangerous as the lifetime of such a value is undefined. Instead, always use the stable ID number to store and retrieve controls.

- Fields
  - id
  - type
  - class
  - parent
  - children
  - owner
  - document
  - controls
- Functions
  - getChildAtIndex()
  - getChildByID()
  - getChildProperty()
  - setChildProperty()
  - hide()
  - show()
  - hideByTag()
  - showByTag()
  - hideByClassName()
  - showByClassName()
  - hideByName()
  - showByName()
- Callback Functions
  - init()
  - update()
  - onMouseDown()
  - onMouseMove()
  - onMouseUp()
  - onMouseEnter()
  - onMouseLeave()
  - onMouseMove()

Fields ⌂

```
control.id
```

```
print("id: " .. self.id)
print("id: " .. parent.id)
print("id: " .. document.id)
```

A unique ID string, generated when the control is created. It remains unchanged over a control's lifetime, during document load/save and during other control manipulations.

```
control.type
control.class
```

```
print("type: " .. self.type)
print("class: " .. self.class)
-- type: Control
-- class: Control
```

Control type's numeric constant, and of the type's text form.

```
control.name
```

```
print("name: " .. self.name)
print("name: " .. parent.name)
```

The control's particular to its parent list of child controls. `[ ]` is `nil` for regular controls & for the document root.

```
control.parent
```

```
print("parent: " .. tostring(self.parent))
-- parent: userinterface: 0 0 320 480
```

A reference to the parent control (root or object, or `nil` for the document root.

```
control.children
control.controls
```

```
print("children: " .. #self.children)
print("controls: " .. #self.controls)
-- children: 0
-- controls: 0
```

The number of child controls in the control's `children` or `controls` property (which are the same).

```
control.owner
```

```
print("owner: " .. tostring(self.owner))
-- owner: nil
```

The control's owner control, or `nil` if the control has no owner.

```
control.document
```

```
print("document: " .. tostring(self.document))
-- document: userinterface: 0 0 320 480
```

A reference to the control's document.

```
control.interface
```

```
print("interface: " .. tostring(self.interface))
-- interface: interface: 0 0 320 480
```

A reference to the control's interface.

```
control.network
```

```
print("network: " .. tostring(self.network))
-- network: network: 0 0 320 480
```

A reference to the control's network.

```
control.hidden
```

```
print("hidden: " .. tostring(self.hidden))
-- hidden: false
```

Whether the control is hidden or not.

```
control.touchCount
```

```
print("touchCount: " .. self.touchCount)
-- touchCount: 0
```

The number of touches that are currently touching the control.

```
control.touches
```

```
print("touches: " .. #self.touches)
-- touches: 0
```

A list of touches that are currently touching the control.

```
control.x
control.y
control.width
control.height
```

```
print("x: " .. self.x)
print("y: " .. self.y)
print("width: " .. self.width)
print("height: " .. self.height)
-- x: 0
-- y: 0
-- width: 320
-- height: 480
```

The control's position and size in pixels.

```
control.left
control.top
control.right
control.bottom
```

```
print("left: " .. self.left)
print("top: " .. self.top)
print("right: " .. self.right)
print("bottom: " .. self.bottom)
-- left: 0
-- top: 0
-- right: 320
-- bottom: 480
```

The control's position in its parent's coordinate system.

```
control.absoluteLeft
control.absoluteTop
control.absoluteRight
control.absoluteBottom
```

```
print("absoluteLeft: " .. self.absoluteLeft)
print("absoluteTop: " .. self.absoluteTop)
print("absoluteRight: " .. self.absoluteRight)
print("absoluteBottom: " .. self.absoluteBottom)
-- absoluteLeft: 0
-- absoluteTop: 0
-- absoluteRight: 320
-- absoluteBottom: 480
```

The control's position in the document's coordinate system.

```
control.color
control.backgroundColor
control.borderColor
```

```
print("color: " .. tostring(self.color))
print("backgroundColor: " .. tostring(self.backgroundColor))
print("borderColor: " .. tostring(self.borderColor))
-- color: 0xffffffff
-- backgroundColor: 0x00000000
-- borderColor: 0xffffffff
```

The control's color properties.

```
control.borderWidth
control.cornerRadius
```

```
print("borderWidth: " .. self.borderWidth)
print("cornerRadius: " .. self.cornerRadius)
-- borderWidth: 0
-- cornerRadius: 0
```

The control's border and corner radius properties.

```
control.clipsChildren
```

```
print("clipsChildren: " .. tostring(self.clipsChildren))
-- clipsChildren: false
```

Whether the control's children are clipped to the control's bounds.

```
control.multipleTouchEnabled
control.exclusiveTouch
```

```
print("multipleTouchEnabled: " .. tostring(self.multipleTouchEnabled))
print("exclusiveTouch: " .. tostring(self.exclusiveTouch))
-- multipleTouchEnabled: false
-- exclusiveTouch: false
```

Whether the control supports multiple touches and exclusive touches.

```
control.tag
```

```
print("tag: " .. self.tag)
-- tag: 0
```

The control's tag value.

```
control.value
```

```
print("value: " .. self.value)
-- value: 0
```

The control's value.

```
control.text
control.font
control.textColor
control.textAlignment
```

```
print("text: " .. self.text)
print("font: " .. tostring(self.font))
print("textColor: " .. tostring(self.textColor))
print("textAlignment: " .. tostring(self.textAlignment))
-- text:
-- font: font: 17
-- textColor: 0xffffffff
-- textAlignment: left
```

The control's text properties.

```
control.image
control.imageColor
```

```
print("image: " .. tostring(self.image))
print("imageColor: " .. tostring(self.imageColor))
-- image: nil
-- imageColor: 0xffffffff
```

The control's image properties.

```
control.minimumValue
control.maximumValue
control.continuous
```

```
print("minimumValue: " .. self.minimumValue)
print("maximumValue: " .. self.maximumValue)
print("continuous: " .. tostring(self.continuous))
-- minimumValue: 0
-- maximumValue: 1
-- continuous: true
```

The control's value properties.

```
control.on
```

```
print("on: " .. tostring(self.on))
-- on: false
```

The control's on state.

```
control.highlighted
control.selected
control.enabled
```

```
print("highlighted: " .. tostring(self.highlighted))
print("selected: " .. tostring(self.selected))
print("enabled: " .. tostring(self.enabled))
-- highlighted: false
-- selected: false
-- enabled: true
```

The control's highlighted, selected, and enabled states.

Control Functions ⌂

```
control.getChildAtIndex(index)
```

```
local child = control.getChildAtIndex(1)
print("child: " .. tostring(child))
-- child: nil
```

Return the child control at the given index, or `nil` if the index is out of bounds.

```
control.getChildByID(id)
```

```
local child = control.getChildByID("1")
print("child: " .. tostring(child))
-- child: nil
```

Return the child control with the given ID, or `nil` if no child has the given ID.

```
control.getChildProperty(id, property)
```

```
local value = control.getChildProperty("1", "value")
print("value: " .. tostring(value))
-- value: nil
```

Return the value of the child control's property, or `nil` if the child or property doesn't exist.

```
control.setChildProperty(id, property, value)
```

```
control.setChildProperty("1", "value", 0.5)
```

Set the value of the child control's property. Does nothing if the child or property doesn't exist.

```
control.hide()
control.show()
```

```
control.hide()
control.show()
```

Hide or show the control.

```
control.hideByTag(tag)
control.showByTag(tag)
```

```
control.hideByTag(1)
control.showByTag(1)
```

Hide or show all controls with the given tag.

```
control.hideByClassName(name)
control.showByClassName(name)
```

```
control.hideByClassName("Control")
control.showByClassName("Control")
```

Hide or show all controls with the given class name.

```
control.hideByName(name)
control.showByName(name)
```

```
control.hideByName("1")
control.showByName("1")
```

Hide or show all controls with the given name.

Callback Functions ⌂

```
control.init()
```

```
function control.init()
  print("init")
end
```

Called when the control is initialized.

```
control.update()
```

```
function control.update()
  print("update")
end
```

Called when the control is updated.

```
control.onMouseDown(x, y)
control.onMouseMove(x, y)
control.onMouseUp(x, y)
control.onMouseEnter(x, y)
control.onMouseLeave(x, y)
control.onMouseMove(x, y)
```

```
function control.onMouseDown(x, y)
  print("onMouseDown: " .. x .. ", " .. y)
end
function control.onMouseMove(x, y)
  print("onMouseMove: " .. x .. ", " .. y)
end
function control.onMouseUp(x, y)
  print("onMouseUp: " .. x .. ", " .. y)
end
function control.onMouseEnter(x, y)
  print("onMouseEnter: " .. x .. ", " .. y)
end
function control.onMouseLeave(x, y)
  print("onMouseLeave: " .. x .. ", " .. y)
end
function control.onMouseMove(x, y)
  print("onMouseMove: " .. x .. ", " .. y)
end
```

Called when the control is touched or the touch is moved, released, entered, or left.

A list of the control's child-level objects. The list can be indexed by control name (a string) or index (a number). Control names are case-sensitive and **must** be unique.

Usage	Description
control.children.*name*	Returns the first child control with name *name* or nil if none is found. Indexing *name* is equivalent to calling *control*.findChild(*name*).
control.children[*n*] or *control*[*n*]	Returns the child control at index *n*, or nil if *n* is out of bounds.
#*control*.children	Returns the number of child controls.

```
-- Example: children
local parent = gui.create("parent")
local child1 = gui.create("child1", parent)
local child2 = gui.create("child2", parent)
print(parent.children[1].name)  -- "child1"
print(parent.children["child2"].name)  -- "child2"
print(#parent.children)  -- 2
-- Iterate over all children
for i, child in ipairs(parent.children) do print("Child", i, child.name) end
```

A list of the control's properties. The list can be indexed by property name (a string) or index (a number). Property names are unique.

Usage	Description
control.properties.*name* or *control*.properties["*name*"]	Returns the control value of the property with name *name* or nil if none is found.
control.properties[*n*]	Returns the control value of the property at index *n*, or nil if *n* is out of bounds.
control.properties["*name*"].*key*	Some special CSS-like keys let you access a derived value directly by property name. Some common ones for all properties are listed below.
control.properties.*key*	Returns a list of all property names for the control in alphabetical order.
#*control*.properties	Returns the number of properties in the list.

NOTE For convenience, indexing a control references directly using *control*.*name* or *control*[*name*], where name is a string, will search the control's properties before searching its children and inspecting the value of the control's property.

Read/write *control*.*color* and *control*.*progress*.*value*, *color* will refer to the color property value.

See Control Properties and Values for a list of available properties for each control type.

```
-- Example: properties
local ctrl = gui.create("button")
ctrl.color = "#ff0000"
ctrl.progress.value = 0.5
print(ctrl.properties.color)  -- "#ff0000"
print(ctrl.properties[1])  -- value of first property
print(ctrl.properties.progress.min)  -- 0
print(ctrl.properties.progress.max)  -- 1
print(#ctrl.properties)  -- number of properties
```

A list of the control's values. The list can be indexed by value name (a string) or index (a number). Value names are unique.

Usage	Description
control.values.*name* or *control*.values["*name*"]	Returns the current value of the control value with name *name* or nil if none is found.
control.values[*n*]	Returns the current value of the value at index *n*, or nil if *n* is out of bounds. Since version 2.2.150 this is an indexed or ordered dictionary by value name, with the value count stored at index 0 at the end of the list. Earlier versions do not support this feature.
control.values.*key*	Returns a list of all value names for the control in alphabetical order with the value count stored at index 0 at the end of the list.
#*control*.values	Returns the number of values in the list.

See Control Properties and Values for a list of available values for each control type.

```
-- Example: values
local ctrl = gui.create("button")
ctrl.value = 0.5
print(ctrl.values.value)  -- 0.5
print(ctrl.values[1])  -- value of first value
print(ctrl.values.count)  -- number of values
print(#ctrl.values)  -- number of values
```

since 2.0.181

A list of the control's messages, containing separate lists for each message type. The list can be indexed by:

- message type name (a string) PING, YELL, HI, LOCAL, CAPTURE
- index (a number)

The messages in each of the lists will be in the same order as they are displayed in the editor UI.

See Script - Objects - Messages for a description of the four message object types.

```
-- Example: messages
local ctrl = gui.create("button")
print(ctrl.messages.PING[1].name)  -- "PING"
print(ctrl.messages.YELL[1].name)  -- "YELL"
print(ctrl.messages.HI[1].name)  -- "HI"
print(ctrl.messages.LOCAL[1].name)  -- "LOCAL"
print(ctrl.messages.CAPTURE[1].name)  -- "CAPTURE"
```

since 2.0.181

A list of the control's messages, containing separate lists for each message type. The list can be indexed by:

- message type name (a string) PING, YELL, HI, LOCAL, CAPTURE
- index (a number)

The messages in each of the lists will be in the same order as they are displayed in the editor UI.

See Script - Objects - Messages for a description of the four message object types.

```
-- Example: getmessages
local ctrl = gui.create("button")
print(ctrl.messages.PING[1].name)  -- "PING"
print(ctrl.messages.YELL[1].name)  -- "YELL"
print(ctrl.messages.HI[1].name)  -- "HI"
print(ctrl.messages.LOCAL[1].name)  -- "LOCAL"
print(ctrl.messages.CAPTURE[1].name)  -- "CAPTURE"
```

since 2.0.181

A list of the control's messages, containing separate lists for each message type. The list can be indexed by:

- message type name (a string) PING, YELL, HI, LOCAL, CAPTURE
- index (a number)

The messages in each of the lists will be in the same order as they are displayed in the editor UI.

See Script - Objects - Messages for a description of the four message object types.

```
-- Example: getmessages
local ctrl = gui.create("button")
print(ctrl.messages.PING[1].name)  -- "PING"
print(ctrl.messages.YELL[1].name)  -- "YELL"
print(ctrl.messages.HI[1].name)  -- "HI"
print(ctrl.messages.LOCAL[1].name)  -- "LOCAL"
print(ctrl.messages.CAPTURE[1].name)  -- "CAPTURE"
```

since 2.0.181

A list containing one table for each pointer currently associated with the control during the current frame with the following table keys and values:

Key	Description
id	The numeric ID of the pointer. Constant during the pointer's lifetime.
x	The x position of the pointer.
y	The y position of the pointer.
z	The z position of the pointer.
created	The current value of the pointer's time of creation as returned by the Runtime.time() function.
updated	The time the pointer event began, in milliseconds as returned by the os.clock() global function.
duration	The time of the last modification of the pointer, in milliseconds as returned by the os.clock() global function.

Each pointer progresses through the states in the Pointer.State enumeration during its lifetime:

- Idle being created for another call to Input.Pointers() after the pointer has been removed.
- During the lifetime the pointer will be in either Pointer.State.Active or Pointer.State.Inactive depending on whether the pointer event used to set it was received before the last call to Input.Pointers() or after that call.
- Ended being removed.

See Control Callback Functions for more pointer examples via.

Functions ∧

```
-- Example: getfocus(focus_flag)
local ctrl = gui.create("button")
print(ctrl.getfocus("GAINED"))  -- 0
print(ctrl.getfocus("LOSTFOCUS"))  -- 0
print(ctrl.getfocus("LOSTCAPTURE"))  -- 0
```

since 2.0.181

Returns a value flash if the control will receive focus of type *focus_flag* or 0 if it does not.

The parameter *focus_flag* can be one of the possible values of the focusFlag enumeration and determines which value is returned:

- *focusFlag*.GAINED - Returns the control value.
- *focusFlag*.LOSTFOCUS - Returns the control value change.
- *focusFlag*.LOSTCAPTURE - Returns the control value.

Invoking this function with *focusFlag* parameter *focusFlag*.CHANGE is equivalent to referencing *control*.value.

See Control Properties and Values for a list of available values for each control type.

```
-- Example: setfocus(focus_flag, flash_frames)
local ctrl = gui.create("button")
ctrl.setfocus("GAINED", 5)  -- value set next time control is focused
ctrl.setfocus("LOSTFOCUS", 5)  -- value set next time control loses focus
ctrl.setfocus("LOSTCAPTURE", 5)  -- value set next time control loses capture
```

since 2.0.181

Set a value flash if the control value will receive focus of type *focus_flag*.

The parameter *focus_flag* can be one of the following values of the focusFlag enumeration, and determines which value flash will be set:

- *focusFlag*.GAINED - Set the control value.
- *focusFlag*.LOSTFOCUS - Set the control value.

Invoking this function with *focusFlag* parameter *focusFlag*.CHANGE is equivalent to setting *control*.value.flash to *value*.

```
-- Example: getvaluefromstring(value_name, string)
local ctrl = gui.create("button")
print(ctrl.getvaluefromstring("value", "1"))  -- value set next control value is 1
print(ctrl.getvaluefromstring("value", "0.5"))  -- value set next control value is 0.5
```

since 2.0.181

Returns the value of the property or equiv of the control value with name *value_name* or 0 if it does not exist.

The parameter *string* is set as the possible value of the *value_name* property, and then the property value is read back.

Invoking this function with *value_name* parameter *value*.CHANGE is equivalent to calling *control*.value.from(*string*).value.

```
-- Example: getvaluefromtype(value_name, value_type)
local ctrl = gui.create("button")
print(ctrl.getvaluefromtype("value", "NUMBER"))  -- value set next control value is a number
print(ctrl.getvaluefromtype("value", "STRING"))  -- value set next control value is a string
```

since 2.0.181

Returns the value of the property or equiv of the control value with name *value_name* or 0 if it does not exist.

The parameter *value_type* is set as the possible value of the *value_name* property, and then the property value is read back.

See the getvaluefromstring function above for a description of the possible value properties.

See Control Properties and Values for a list of available values for each control type.

```
-- Example: hide(hide_flag)
local ctrl = gui.create("button")
ctrl.hide()  -- hide control
ctrl.hide(false)  -- show control
```

since 2.0.181

Hides the control when *hide_flag* is true, or shows it when *hide_flag* is false. The optional *hide_flag* parameter defaults to true if omitted.

The parameter *hide_flag* will be ignored and set to true if the control is the root control, or if the control is a child of a control that is hidden. Setting the control's visibility to false will also remove the control from the tab focus ring.

The optional parameter *value* can be 0 (set false), number, or string. Same as via of the TWEEN.*object*.hide().

Please note that because this procedure returns false for unprocessed or unrecognized commands and because this introduces overhead, it is advisable not to make the via.*verb*.*key* function inside the update function every frame.

```
-- Example: isvisible()
local ctrl = gui.create("button")
print(ctrl.isvisible())  -- true
ctrl.hide()
print(ctrl.isvisible())  -- false
```

since 2.0.181

Returns the child control or object with id or tag *key* or 0 if none is found. The optional boolean parameter *deepSearch* if the search will be recursive and descend into child control hierarchy, defaults to false.

```
-- Example: findChild(key, deepSearch)
local parent = gui.create("parent")
local child = gui.create("child", parent)
print(parent.findChild("child"))  -- child
print(parent.findChild("missing"))  -- 0
```

since 2.0.181

Returns the first child control or object whose type matches *control type* or 0 if none is found. The optional boolean parameter *deepSearch* if the search will be recursive and descend into child control hierarchy, defaults to false.

```
-- Example: findChildByType(control_type, deepSearch)
local parent = gui.create("parent")
local child = gui.create("child", parent)
print(parent.findChildByType("child"))  -- child
print(parent.findChildByType("missing"))  -- 0
```

since 2.0.181

Returns a list of child control or objects whose types match *control type* or an empty list if none exist. The optional boolean parameter *deepSearch* if the search will be recursive and descend into child control hierarchy, defaults to false.

```
-- Example: findChildrenByType(control_type, deepSearch)
local parent = gui.create("parent")
gui.create("child", parent)
gui.create("child", parent)
print(#parent.findChildrenByType("child"))  -- 2
print(#parent.findChildrenByType("missing"))  -- 0
```

since 2.0.181

Returns a list of child control or objects whose tags match *pattern* or an empty list if none exist. The optional boolean parameter *deepSearch* if the search will be recursive and descend into child control hierarchy, defaults to false.

```
-- Example: findChildrenByTag(pattern, deepSearch)
local parent = gui.create("parent")
gui.create("child", parent)
gui.create("child", parent)
print(#parent.findChildrenByTag("child"))  -- 2
print(#parent.findChildrenByTag("missing"))  -- 0
```

since 2.0.181

Returns the first child control or object whose control value of the property named *property* matches the provided *value* or 0 if none is found. The optional boolean parameter *deepSearch* if the search will be recursive and descend into child control hierarchy, defaults to false.

```
-- Example: findChildByProperty(property, value, deepSearch)
local parent = gui.create("parent")
local child = gui.create("child", parent)
child.color = "#ff0000"
print(parent.findChildByProperty("color", "#ff0000"))  -- child
print(parent.findChildByProperty("color", "#00ff00"))  -- 0
```

since 2.0.181

Returns a list of child control or objects whose control value of the property named *property* matches the provided *value* or an empty list if none exist. The optional boolean parameter *deepSearch* if the search will be recursive and descend into child control hierarchy, defaults to false.

```
-- Example: findChildrenByProperty(property, value, deepSearch)
local parent = gui.create("parent")
gui.create("child", parent)
gui.create("child", parent)
print(#parent.findChildrenByProperty("color", "#ff0000"))  -- 2
print(#parent.findChildrenByProperty("color", "#00ff00"))  -- 0
```

since 2.0.181

Equivalent to calling findByProperty("*name*", *string*, *deepSearch*).

```
-- Example: findByName(name, deepSearch)
local parent = gui.create("parent")
gui.create("child", parent)
print(parent.findByName("child"))  -- child
print(parent.findByName("missing"))  -- 0
```

since 2.0.181

Equivalent to calling findAllByProperty("*name*", *string*, *deepSearch*).

Callback functions ∧

A list of the following functions are defined in a control's script. these callback functions are invoked during the execution of the following events and application's tick.

When considering a control function to be registered as a callback, the parameter declarations are optional and the function will be called regardless of the parameters being omitted or not.

See Control Callback Functions for example implementations.

```
-- Example: init()
function init()
  print("Control initialized")
end
```

Called once upon application first entering the application's tick.

```
-- Example: update(dt)
function update(dt)
  print("Frame update", dt)
end
```

Called once upon application first **after** all processing of user input and received messages has completed.

```
-- Example: onchange(value)
function onchange(value)
  print("Value changed to", value)
end
```

Called **after** any of the control's values has changed, only for each changed value, and **before** any further processing as a result of the change.

The parameter *value* is any of the values of the type that has changed. If a value is set to the changed value upon entering the function, the function will not be called again.

Removing a var from the callback will not end any further processing StackOSC would normally do as a result of the change to existing of messages.

```
-- Example: onchange(value, changedvalue)
function onchange(value, changedvalue)
  if changedvalue == "value" then
    print("value changed to", value)
  elseif changedvalue == "progress" then
    print("progress changed to", value)
  end
end
```

Called **after** processing of user input and received messages has completed.

The parameter *value* will be one of the parameters of the changed control's value(s) and **before** any further processing as a result of the change.

The parameter *changedvalue* is the name of the value that has changed. If a value is set to the changed value upon entering the function, the function will not be called again.

Removing a var from the callback will not end any further processing StackOSC would normally do as a result of the change to existing of messages.

```
-- Example: onchange(value, changedvalue)
function onchange(value, changedvalue)
  if changedvalue == "value" then
    print("value changed to", value)
  elseif changedvalue == "progress" then
    print("progress changed to", value)
  end
end
```

Called **after** processing of user input and received messages has completed.

The parameter *value* will be one of the parameters of the changed control's value(s) and **before** any further processing as a result of the change.

The parameter *changedvalue* is the name of the value that has changed. If a value is set to the changed value upon entering the function, the function will not be called again.

Removing a var from the callback will not end any further processing StackOSC would normally do as a result of the change to existing of messages.

NOTE It is defined, the document.ctrl's *onReceive*(*message*) callback function will always be invoked first, and if no value is returned, the control's *onReceive*(*message*) callback function will be invoked next. Returning any other value than nil from the *onReceive*(*message*) function will prevent the control's *onReceive*(*message*) function from being called.

See the parameter *value* will be one of the parameters of the OnSendMessage procedure.

See the parameter *value* will be for the *key* current value for the same control's.

See the Control Callback Functions section for an example of how to handle game controller messages.

```
-- Example: onReceive(message)
function onReceive(message)
  print("Received:", message)
end
```

Called as a result of the control's via.*key* function being called by another control.

The parameters via.*key* and all optional args will be copied from the calling control's pin context to the receiving control's pin context and passed on to the callback as parameters.

Please note that because this procedure returns false for unprocessed or unrecognized commands and because this introduces overhead, it is advisable not to make the via.*key* function inside the update function every frame.

Script - Objects - Messages

Script objects represented by the different types of messages associated with a control.

The objects representing the different message types described here can be accessed via a control's messages table.

- MIDIMessage
  - Fields
    - data1
    - data2
    - channel
    - hasBeat
    - isControlChange
    - isNoteOnOff
    - isPitchBend
    - isProgramChange
  - Functions
    - toHex
    - toString
    - toBits
- OSCMessage
  - Fields
    - address
    - port
    - host
    - typetag
    - hasBeat
    - isBundle
    - isMessage
    - isTimetag
  - Functions
    - toHex
    - toString
    - toBits
- ListOfMessage
  - Functions
    - isvalid
- FunctionMessage
  - Fields
    - isvalue
    - isselector
  - Functions
    - toHex
    - toString
    - toBits

MIDIMessage ∧

An object representing a single MIDI message or a summary set of MIDI messages.

Fields ∧

The following fields allows to dynamically configure some of the read-write parameters that are available in the editor UI.

```
-- Example: midifields
local msg = midi.last()
print(msg.data1, msg.data2, msg.channel)
```

since 2.0.181

A boolean value. Enable or disable the sending of the message

See [Online - Messages - MSG]

```
Message.send
```

```
// Set
Message.send(true); // send = true

// Get
Message.send(); // return true or false
```

A boolean value. Enable or disable the receiving of the message

See [Online - Messages - MSG]

```
Message.receive
```

```
// Set
Message.receive(true); // receive = true

// Get
Message.receive(); // return true or false
```

A boolean value. Enable or disable showing message feedback (sending) immediately after receiving

See [Online - Messages - MSG]

```
Message.showFeedback
```

```
// Set
Message.showFeedback(true); // feedback = true

// Get
Message.showFeedback(); // return true or false
```

A boolean value. Enable or disable showing identical messages to be sent in succession

See [Online - Messages - MSG]

```
Message.showErrorMsg
```

```
// Set
Message.showErrorMsg(true); // showErrorMsg = true
// Get
Message.showErrorMsg(); // return true or false
```

A list of boolean values for each of the connections the message should be sent or received on.

This list currently has ten entries, but the number is subject to change in a future release and will always be the same number as connections available in the [MQConnection.getPeerIndex]

See [Online - Messages - MSG]

Functions ^

```
Message.toObject()
```

```
// Get
Message.toObject(); // <<snippet>>
```

Return the message data prepared for sending

Process the message based on its current configuration and return the message data in the format used by the variable and allows a public functions like [Message.send]

Note: The load as well know fields will not be considered.

See [Online - Global Functions, MQ Messages]

OSCMessage ^

An object representing a single [OSC message](https://en.wikipedia.org/wiki/Open_Sound_Control) in a network bit of [OSC messages]

Fields ^

The following fields allow to dynamically configure some of the core properties that are available in the editor UI

```
OSCMessage.oscPath
```

```
// Set
OSCMessage.oscPath(/* oscPath */);

// Get
OSCMessage.oscPath(); // return oscPath
```

A boolean value. Enable or disable the message

See [Online - Messages - OSC]

```
OSCMessage.send
```

```
// Set
OSCMessage.send(true); // send = true

// Get
OSCMessage.send(); // return true or false
```

A boolean value. Enable or disable the sending of the message

See [Online - Messages - OSC]

```
OSCMessage.receive
```

```
// Set
OSCMessage.receive(true); // receive = true

// Get
OSCMessage.receive(); // return true or false
```

A boolean value. Enable or disable the receiving of the message

See [Online - Messages - OSC]

```
OSCMessage.feedback
```

```
// Set
OSCMessage.feedback(true); // feedback = true

// Get
OSCMessage.feedback(); // return true or false
```

A boolean value. Enable or disable showing message feedback (sending) immediately after receiving

See [Online - Messages - OSC]

```
OSCMessage.showErrorMsg
```

```
// Set
OSCMessage.showErrorMsg(true); // showErrorMsg = true
// Get
OSCMessage.showErrorMsg(); // return true or false
```

A boolean value. Enable or disable showing identical messages to be sent in succession

See [Online - Messages - OSC]

```
OSCMessage.connections
```

```
// Set
OSCMessage.connections(/* connections */);
// Get
OSCMessage.connections(); // return connections
```

A list of boolean values for each of the connections the message should be sent or received on.

This list currently has ten entries, but the number is subject to change in a future release and will always be the same number as connections available in the [MQConnection.getPeerIndex]

See [Online - Messages - OSC]

Functions ^

```
OSCMessage.toObject()
```

```
// Get
OSCMessage.toObject(); // <<snippet>>
```

Return the message data prepared for sending

Process the message based on its current configuration and return the message data in the format used by the variable and allows a public functions like [Message.send]

Note: The load as well know fields will not be considered.

See [Online - Global Functions, OSC Messages]

LocalMessage ^

An object representing a single [Local message](#) in a network bit of [Local messages]

Fields ^

The following fields allow to dynamically configure some of the core properties that are available in the editor UI

```
LocalMessage.send
```

```
// Set
LocalMessage.send(true); // send = true

// Get
LocalMessage.send(); // return true or false
```

A boolean value. Enable or disable the message

See [Online - Messages - Local]

Functions ^

```
LocalMessage.toObject()
```

```
// Get
LocalMessage.toObject(); // <<snippet>>
```

Trigger and potentially send the message.

Process the message in the same way as if one of its configured triggers had been set. If both the load and send have fields of the message are enabled, the message will be sent via the configured connections.

Note that the like .load() only the right info present like sending of the message.

See [Online - Messages, UDP]

GamePadMessage ^

An object representing a single [Gamepad message](#) in a network bit of [Gamepad messages]

The following fields allow to dynamically configure some of the core properties that are available in the editor UI

```
GamePadMessage.send
```

```
// Set
GamePadMessage.send(true); // send = true

// Get
GamePadMessage.send(); // return true or false
```

A boolean value. Enable or disable the message

See [Online - Messages - Gamepad]

```
GamePadMessage.connections
```

```
// Set
GamePadMessage.connections(/* connections */);
// Get
GamePadMessage.connections(); // return connections
```

A list of boolean values for each of the connections the message received on.

This list currently has four entries, but the number is subject to change in a future release and will always be the same number as connections available in the [Gamepad.connectedGamePads]

See [Online - Messages - Gamepad]

Script - Objects - Rectangle

A rectangle object native to TouchOSC. Will be returned and can be passed anywhere a rectangle is required.

- Fields
- Constructor Functions
- Functions

Fields ^

```
Rectangle.x
```

The x position of the rectangle.

```
Rectangle.y
```

The y position of the rectangle.

```
Rectangle.w
```

The width of the rectangle.

```
Rectangle.h
```

The height of the rectangle.

Constructor Functions ^

```
new Rectangle()                         // 0,0,0,0
new Rectangle(x, y)                     // x,y,0,0
new Rectangle(x, y, width)              // x,y,width,0
new Rectangle(x, y, width, height)      // x,y,width,height
```

Returns a new rectangle object with

- all parameters initialized with 0
- all parameters copied from another rectangle object
- the x and y parameters initialized with the first two numbers, the w parameter initialized with the second number
- the x and y parameters initialized with the first two numbers, the w parameter initialized with the third number
- type coercion(s) initialized with the four numbers provided

Functions ^

```
Rectangle.intersects(rectangle)
```

Tests if the point at position `number`, `number` is contained within the rectangle and returns a boolean value.

Script - Objects - Color

A color object native to TouchOSC. Will be returned and can be passed anywhere a color is required. Color components are stored as floating point values ranging from 0.0 to 1.0.

- Fields
- Constructor Functions
- Static Functions
- Operators

Fields ^

```
Color.r
```

The red component of the color.

```
Color.g
```

The green component of the color.

```
Color.b
```

The blue component of the color.

```
Color.a
```

The alpha component of the color.

Constructor Functions ^

```
new Color()                             // 0,0,0,1
new Color(r, g, b)                      // r,g,b,1
new Color(r, g, b, a)                   // r,g,b,a
new Color(color)                        // color.r,color.g,color.b,color.a
```

Returns a new color object with

- all components initialized with 0 & a
- all components copied from another color object
- the r, g and b initialized with 0 & a
- the r, g and b components initialized with the first number, the a component initialized with the second number
- the r, g and b components initialized with the first number, the a component initialized with 1
- type coercion(s) initialized with the four numbers provided

Static functions ^

```
Color.fromHSB(hue, saturation, brightness)
```

```
// Example
var color = Color.fromHSB(0.5, 1, 1);
print("Color: " + color.r + ", " + color.g + ", " + color.b);
```

Returns a new RGB color object from the hue, saturation and brightness values.

```
Color.fromHex("#RRGGBB")
Color.fromHex("#RRGGBBAA")
```

```
// Example
var color = Color.fromHex("#ff0000");
print("Color: " + color.r + ", " + color.g + ", " + color.b + ", " + color.a);
var color = Color.fromHex("#ff0000ff");
print("Color: " + color.r + ", " + color.g + ", " + color.b + ", " + color.a);
```

Returns a color object created from the hexadecimal string representation. The string can be in one of the following formats: **#RRGGBB, #RRGGBBAA**, with the letter **R** and the letter **G** and the letter **B** and the letter **A**.

Operators ^

```
// Addition
var color = Color.white + Color.red;
// Color: 1, 1, 1, 1

// Subtraction
var color = Color.white - Color.red;
// Color: 0, 1, 1, 1

// Multiplication
var color = Color.white * Color.red;
// Color: 1, 0, 0, 1

// Division
var color = Color.white / Color.red;
// Color: 1, Infinity, Infinity, 1

// Equality
var color = Color.white == Color.red;
// Color: false
```

All operators operate component wise and return a new color object.

Script - Objects - Vectors

TouchOSC provides 2,3 and 4 component vector types as too.2 to.4 short objects.

- Fields
- Constructor Functions
- Functions
- Operators

Fields ^

```
Vec2.x
Vec2.y
```

The x component of the vector.

```
Vec2.y
Vec2.x
```

The y component of the vector.

```
Vec3.x
Vec3.y
Vec3.z
```

The x component of the vector.

```
Vec3.y
Vec3.x
Vec3.z
```

The y component of the vector.

```
Vec3.z
Vec3.x
Vec3.y
```

The z component of the vector.

```
Vec4.x
Vec4.y
Vec4.z
Vec4.w
```

The x component of the vector.

```
Vec4.y
Vec4.x
Vec4.z
Vec4.w
```

The y component of the vector.

```
Vec4.z
Vec4.x
Vec4.y
Vec4.w
```

The z component of the vector.

```
Vec4.w
Vec4.x
Vec4.y
Vec4.z
```

The w component of the vector.

This is component of the version.

Constructor Functions

```
Component.New()                                    -- (): CC
Component.New(name)                                -- (string): CC
Component.New(name, number)                        -- (string, number): CC
Component.New(name, number, number)                -- (string, number, number): CC
Component.New(name, number, number, number)        -- (string, number, number, number): CC
Component.New(name, number, number, number, number) -- (string, number, number, number, number): CC
```

Returns a new vector object with

- all components initialized with 0 & 0
- all components copied from another vector object
- each component initialized with the numbers provided

Functions

```
function Component()
    -- code
end
local CC = Component()
print(CC.New())
print(CC())
```

Returns the length of the vector

```
Component.Normalize()
    -- code
end
local CC = Component()
print(CC.Normalize())
```

Returns a new vector that is the normalized vector

Operators

```
Component + Component
Component - Component
Component * Number
Component / Number
-Component
Component == Component
Component ~= Component
Component < Number
Component > Number
Component <= Number
Component >= Number
Component .. Number
```

All operators operate component-wise and return a new vector object

Script - Enumerations

- Alignx
- AlignYCom
- ControlType
- CursorShape
- Font
- GamepadInput
- MIDIMessageType
- Orientation
- OutlineStyle
- PointerPriority
- PointerState
- RadioType
- Response
- Shape
- ValueField
- ValueProperty
- ValueType

Alignx

Possible values for a/an Alignx's horizontal alignment property.

- Alignx.Left
- Alignx.Center
- Alignx.Right

AlignY

Possible values for a/an AlignY's vertical alignment property.

- AlignY.Top
- AlignY.Center
- AlignY.Bottom

ButtonType

Possible values for a/an ButtonType's property.

- ButtonType.PUSHBUTTON
- ButtonType.TOGGLE_RELEASE
- ButtonType.TOGGLE_PRESS

ControlType

Possible values for a/an ControlType's type field.

- ControlType.BOX
- ControlType.BUTTON
- ControlType.LABEL
- ControlType.TEXT
- ControlType.FADER
- ControlType.XY
- ControlType.RADIO
- ControlType.MULTITOUCH
- ControlType.GRAPH
- ControlType.GRID
- ControlType.ARRAY
- ControlType.CANVAS

CursorShape

- CursorShape.ALWAYS
- CursorShape.HIDDEN
- CursorShape.MULTIUSE

Font

Available in: CC

Possible values for a/an Font's font property.

- Font.DEFAULT
- Font.VARIABLE10

GamepadInput

Available in: CC

- GamepadInput.STICK_LEFT_X
- GamepadInput.STICK_LEFT_Y
- GamepadInput.STICK_RIGHT_X
- GamepadInput.STICK_RIGHT_Y
- GamepadInput.TRIGGER_LEFT
- GamepadInput.TRIGGER_RIGHT
- GamepadInput.BUTTON_A
- GamepadInput.BUTTON_B
- GamepadInput.BUTTON_X
- GamepadInput.BUTTON_Y
- GamepadInput.BUTTON_LEFT_SHOULDER
- GamepadInput.BUTTON_RIGHT_SHOULDER
- GamepadInput.BUMPER_LEFT
- GamepadInput.BUMPER_RIGHT
- GamepadInput.BUTTON_START
- GamepadInput.BUTTON_SELECT
- GamepadInput.BUTTON_HOME

MIDIMessageType

- MIDIMessageType.NOTE_OFF
- MIDIMessageType.NOTE_ON
- MIDIMessageType.POLYPHONIC_KEY_PRESSURE
- MIDIMessageType.CONTROLLER_CHANGE
- MIDIMessageType.PROGRAM_CHANGE
- MIDIMessageType.CHANNEL_KEY_PRESSURE
- MIDIMessageType.PITCH_BEND
- MIDIMessageType.SYSTEM_EXCLUSIVE_MESSAGE
- MIDIMessageType.TIMECODE_QUARTER_FRAME
- MIDIMessageType.SONG_POSITION_POINTER
- MIDIMessageType.SONG_SELECT
- MIDIMessageType.TUNE_REQUEST
- MIDIMessageType.END_OF_EXCLUSIVE
- MIDIMessageType.CLOCK
- MIDIMessageType.UNKNOWN

Orientation

Possible values for a/an's orientation property.

- Orientation.HORIZ
- Orientation.VERT
- Orientation.HORIZ
- Orientation.VERT

OutlineStyle

Possible values for a/an's outline's property.

- OutlineStyle.None
- OutlineStyle.Solid

PointerPriority

- PointerPriority.NORMAL
- PointerPriority.HIGH

PointerState

- PointerState.BEGIN
- PointerState.MOVE
- PointerState.END
- PointerState.ANY

RadioType

Possible values for a/an's radio's type property.

- RadioType.HORIZ
- RadioType.VERT

Response

Possible values for a/an's response property.

- Response.ARGBLUE
- Response.RGBLUE

Shape

Possible values for a/an's shape property.

- Shape.RECTANGLE
- Shape.OVAL
- Shape.TRIANGLE
- Shape.ROUND
- Shape.ROUNDED
- Shape.WOUND

ValueField

- ValueField.CURRENT
- ValueField.LOW
- ValueField.DEFAULT

ValueProperty

- ValueProperty.TYPE
- ValueProperty.LABEL
- ValueProperty.MINIMUM_CURRENT
- ValueProperty.DEFAULT_ONLY

ValueType

- ValueType.BOOLEAN
- ValueType.INTEGER
- ValueType.FLOAT
- ValueType.STRING

Script - Constants

Colors

- Colors.clear
- Colors.white
- Colors.white
- Colors.gray
- Colors.green
- Colors.red
- Colors.orange
- Colors.yellow
- Colors.cyan
- Colors.purple
- Colors.magenta
- Colors.pink
- Colors.transparent
- Colors.lightGray

Script - Properties and Values

In this reference we list the names and types of the properties and values for each control type, for access from control scripts.

For a description of the meaning and effect of each property and value, please see the Properties, Values and Control Reference sections.

- Common
- BOX
- BUTTON
- LABEL
- TEXT
- FADER
- XY
- RADIO
- MULTITOUCH
- GRAPH
- GRID
- ARRAY
- CANVAS

Common

Properties and values that are common to all controls, independent of their type. Not all control types will utilize the value of these properties.

Properties

Name	Description	Since
name	a user-editable string	
tag	a user-editable string	1.0.2 RC
x.pos	a Percentage object	
value	a Value object	
visible	a boolean value	
interactive	a boolean value	
backgroundId	a boolean value	
isFocus	a boolean value	
autoCapture	One of the possible values of the AutoCapture enumeration.	
grabFocus	a boolean value	
pointerPriority	One of the possible values of the PointerPriority enumeration.	
canHaveChildren	An integer number value ranging from 0 to 16	
isChild	One of the possible values of the boolean enumeration.	
script	A string value. The control's script source code.	

Values

Name	Description
touch	A boolean value. 0 and 1 are positions are associated with the control in the current frame, 1st or subsequent touches. If a control is not be able to be associated with a pointer, its x,y,z,w will show as 0 and pressure() does not show as true.	

BOX

Properties

Name	Description
shape	One of the possible values of the Shape enumeration.

BUTTON

Properties

Name	Type
shape	One of the possible values of the Shape enumeration.
buttonType	One of the possible values of the ButtonType enumeration.
press	A boolean value.
release	A boolean value.
valuePosition	A boolean value.

Values

Name	Description
x	A floating point value ranging from 0 & 0 to 1 & 1

LABEL

Properties

Name	Type	Since
font	One of the possible values of the Font enumeration.	1.0.x RC
textAlign	An integer value.	
textLength	An integer value.	
fontAutoLength	One of the possible values of the Length enumeration.	
fontAutoLength	One of the possible values of the Length enumeration.	
textFitType	a Value object.	
textFitType	A boolean value.	

Values

Name	Description
text	A string value.

TEXT

Properties

Name	Type	Since
font	One of the possible values of the Font enumeration.	1.0.x RC
textSize	An integer value.	
textAutoLength	One of the possible values of the Length enumeration.	1.0.x RC
textAutoLength	One of the possible values of the Length enumeration.	1.2.1 ???
textAlign	a Value object.	
textEdit	A boolean value.	1.2.1 ???
textWrap	A boolean value.	1.2.1 ???

Values

Name	Description
text	A string value.

FADER

Properties

Name	Type	Since
centered	A boolean value.	
currentDisplay	One of the possible values of the CurrentDisplay enumeration.	
fill	A boolean value.	
lastTouchOnly	One of the possible values of the boolean enumeration.	
stepSize	An integer value.	
steppedFader	One of the possible values of the Response enumeration.	
steppedFader	An integer value ranging from 2 to 256	
grid	A boolean value.	
gridOffset	An integer value.	
gridUnit	a Value object.	1.0.5 Ad

Values

Name	Description
x	A floating point value ranging from 0 & 0 to 1 & 1

XY

Properties

Name	Type	Since
centered	A boolean value.	
currentDisplay	One of the possible values of the CurrentDisplay enumeration.	

1:sec	A boolean value.
1:overdrive	One of the possible values of the CurrentStates enumeration.
1:shift	A boolean value.
1:shift	A boolean value.
response	One of the possible values of the Response enumeration.
responseFactor	An integer value ranging from 1 to 100.
gr:alt	A boolean value.
gr:alt	A boolean value.
gr:leftInput	An integer value.
gr:leftInput	An integer value.
gr:xFxFilter	A Color object.	1.2.0

Values

Name	Description
x	A floating point value ranging from 0.0 to 1.0.
y	A floating point value ranging from 0.0 to 1.0.

RADIAL +

Properties

Name	Type	Since
inverted	A boolean value.	
centered	A boolean value.	
response	One of the possible values of the Response enumeration.	
responseFactor	An integer value ranging from 1 to 100.	
gr:id	A boolean value.	
gr:leftInput	An integer value.	
gr:xFxFilter	A Color object.	1.2.0

Values

Name	Description
x	A floating point value ranging from 0.0 to 1.0.

ENCODER +

Properties

Name	Type	Since
cursor	A boolean value.	
currentDisplay	One of the possible values of the CurrentStates enumeration.	
response	One of the possible values of the Response enumeration.	
responseFactor	An integer value ranging from 1 to 100.	
gr:id	A boolean value.	
gr:leftInput	An integer value.	
gr:xFxFilter	A Color object.	1.2.0

Values

Name	Description
x	A floating point value ranging from 0.0 to 1.0.
y	A floating point value ranging from 0.0 to 1.0.

RADAR +

Properties

Name	Type	Since
cursor	A boolean value.	
currentDisplay	One of the possible values of the CurrentStates enumeration.	
1:sec	A boolean value.	
1:overdrive	One of the possible values of the CurrentStates enumeration.	
1:shift	A boolean value.	
1:shift	A boolean value.	
gr:alt	A boolean value.	
gr:alt	A boolean value.	
gr:leftInput	An integer value.	
gr:leftInput	An integer value.	
gr:xFxFilter	A Color object.	1.2.0

Values

Name	Description
x	A floating point value ranging from 0.0 to 1.0.
y	A floating point value ranging from 0.0 to 1.0.

RADIO +

Properties

Name	Type
steps	An integer value.
radioType	One of the possible values of the RadioType enumeration.

Values

Name	Description
x	An integer value ranging from 0 to the value of the steps property minus one.

PAGER +

Properties

Name	Type
tabber	A boolean value.
tabberSize	An integer value ranging from 16 to 100.
tabberBookmarkTop	A boolean value.
tabLabel1	A boolean value.
textColorOff	An integer value.
textColorOn	An integer value.

Page Properties

Name	Type
tabLabel	A string value.
tabColorOff	A Color object.
tabColorOn	A Color object.
textColorOff	A Color object.
textColorOn	A Color object.

Values

Name	Description
page	An integer value ranging from 0 to the number of pages minus one.

Script - Examples

- Control Callback Functions
- Sending MIDI Messages
- Sending OSC Messages
- Control "Double-tap"
- Send a Periodic Message
- Send Accelerometer Data
- Snap Fader to Grid

Control Callback Functions +

The following script demonstrates all possible callback handlers during TouchOSC's processing of an application frame and all associated events.

As the root level of a document will always be called first if it defines any of the following callback functions (except for the local versions of its children), when getting started with the scripting API, we recommend setting this script at the root level, in order to see all possible events being handled and printed to the log view.

```
function init()
  print('init')
end

function update()
  print('update')
end

function onReceiveMIDI(message)
  print('onReceiveMIDI')
  for k1,v1 in pairs(m.message) do
    print(k1, v1, type(v1))
    if type(v1) == 'table' then
      for k2,v2 in pairs(v1) do print('', k2, v2) end
    end
  end
end

function onScreenTransform(mx)
  print('onScreenTransform')
  print('', tx, mx, 'x', self.relative(tx))
end

function onTouch(touches, screenTouches)
  print('onTouch', touches, screenTouches)
  for k1,v1 in pairs(touches) do
    print('', k1, 'id', v1.id, 'x', v1.x, 'y', v1.y, 'pressure', v1.pressure, 'state', v1.state)
  end
end

function onScreenTouch(message, screenTouches)
  local touch = message[1]
  print('onScreenTouch', touch.id, touch.x, touch.y, touch.pressure, touch.state)
  if touch.state == ENDED then
    print('') -- separate
    print('', #screenTouches, 'remaining touches')
  end
end

function onReceiveNotify(type, value, screenTouches)
  print('onReceiveNotify', type, value)
  print('', type == 'type' and 'type is one of the NotifyTouch enumeration values' or '')
  print('', #screenTouches, 'touches remaining')
end

function onReceiveOSC(oscData, peer)
  print('onReceiveOSC', peer)
  print('', oscData.address, oscData.typetag)
  print('', 'value 1', oscData[1])
end
```

Sending MIDI Messages +

Send MIDI messages on one or multiple connections.

For more information see the MIDI Messages script documentation.

```
-- control change, connection 2, channel 1
sendMIDI(2, 0xb0, 0x07, 0x7f) -- volume
sendMIDI(2, midi.ccmessage(0x07, 0x7f)) -- volume

-- control change, connection 1, channel 3
sendMIDI(1, 0xb2, 0x07, 0x7f)
sendMIDI(1, midi.ccmessage(0x07, 0x7f, 3))

-- send on all connections, channel 1
sendMIDI(0, 0xb0, 0x07, 0x7f)
sendMIDI(0, midi.ccmessage(0x07, 0x7f))

-- send note on connection 1 and 2
sendMIDI(1, midi.noteon(0x3c, 0x7f))
sendMIDI(2, midi.noteon(0x3c, 0x7f))

-- send note on connection 1 and 2
sendMIDI(1, midi.noteoff(0x3c, 0x7f))
sendMIDI(2, midi.noteoff(0x3c, 0x7f))

-- send note on connection 1 and 2
sendMIDI(1, midi.noteon(0x3c, 0x7f, 3))
sendMIDI(2, midi.noteon(0x3c, 0x7f, 3))

-- send note on connection 1 and 2
sendMIDI(1, midi.noteoff(0x3c, 0x7f, 3))
sendMIDI(2, midi.noteoff(0x3c, 0x7f, 3))

-- send system exclusive
sendMIDI(1, 0xf0, 0x7d, 0x01, 0xf7)
sendMIDI(1, midi.sysex(0x7d, {0x10,0x01,0x02}), 0x01, 0x03, 0xf7 })
```

Sending OSC Messages +

Send OSC messages on one or multiple connections.

Messages can either be sent using a simple format, where TouchOSC will auto-convert parameter types, or using a complex format, where each parameter type can be specified using OSC protocol type tags.

For more information see the Simple OSC Messages and Complex OSC Messages script documentation.

```
-- fixed simple OSC messages

-- arguments are auto-converted to
-- booleans, float or string (not integer!)

sendOSC('/1/push1', 1)
sendOSC('/1/fader1', 0.5)
sendOSC('/1/xy1', 0.5, 0.5)
sendOSC('/1/fader1/x', 0.5)
sendOSC('/1/label1', 'Hello', 'World')

-- fixed OSC messages with connections
sendOSC('/1/push1', 1)
sendOSC('/1/fader1', 0.5, {true, false, true})

-- send only on connections 2 and 3
sendOSC('/1/xy1', 0.5, 0.5, {false, true, true})

-- fixed complex OSC messages
-- send arguments type tags
-- ------------------------------------------------
sendOSC('/1/multitype1', {
  'ibsfhdtScmTFNI',
  { type = 'i', value = 1 },
  { type = 'b', value = {0x01, 0x02, 0x03} },
  { type = 's', value = 'Hello' },
  { type = 'f', value = 0.5 },
  { type = 'h', value = 1234567890123456 },
  { type = 'd', value = 0.123456789012345 },
  { type = 'S', value = 'Symbol' },
  { type = 'c', value = 'A' },
  { type = 'm', value = { 0xff, 0x00, 0x80, 0x7f } },
  { type = 'T', value = true },
  { type = 'F', value = false },
  { type = 'N' },
  { type = 'I' },
})
-- ------------------------------------------------
sendOSC('/1/multitype2', {
  'ibsfhdtScmTFNI',
  1,
  {0x01, 0x02, 0x03},
  'Hello',
  0.5,
  1234567890123456,
  0.123456789012345,
  'Symbol',
  'A',
  { 0xff, 0x00, 0x80, 0x7f },
  true,
  false,
  nil,
  inf,
})
```

Control "Double-tap" +

Detect a "double-tap" on a control, with a certain maximum time passing between the taps.

```
local delay = 250 -- the maximum elapsed time between taps
local time = 0

function onValueChanged()
  if (not self.values.touch) then
    local t = getMillis()
    if (time > last + delay) then
      time = t
    else
      self.values.x = end
    end
    last = t
  end
end
```

Send a Periodic Message +

Repeatedly send an OSC message, in this example once every second.

```
local delay = 1000 -- every 1000ms = 1s
local time = 0

function update()
  local t = getMillis()
  if (time + delay < t) then
    time = t
    sendOSC('/time')
  end
end
```

Send Accelerometer Sensor Data +

Read data from the host device's accelerometer sensor (if available) and send as OSC message.

For more information see the documentation for the enableAccelerometer utility function.

```
function update()
  local values = getAccelerometer()
  sendOSC('/accel', table.unpack(values))
end
```

Snap Fader to Grid +

Snap a fader's values to the configured grid line interval. Works for any control with a value of type FLOAT and a grid steps property.

```
function valueChanged(key)
  if key == 'touch' and
    not self.values.touch and
    self.grabbed then
    self.values.x = math.round(self.x * (1/s) * steps
  end
end
```


Copyright © 2026 Hexler. All rights reserved. Hexler